

# Robot Controller Safety Function Manual

Original instructions Control Unit RC700-E/RC800 series

©Seiko Epson Corporation 2023-2025

## **Table of Contents**

| 1. Introduction   | 5  |
|---|----|
| 1.1 Introduction  | 6  |
| 1.2 Trademarks  | 6  |
| 1.3 Notation  | 6  |
| 1.4 Terms of Use  | 6  |
| 1.5 Manufacturer  | 6  |
| 1.6 Contact Information   | 6  |
| 1.7 Before Use  | 7  |
| 1.8 Setting by Using Software                                       | 7  |
| 1.9 Training  | 7  |
| 2. Overview of the Robot Controller Safety Functions                | 8  |
| 2.1 Explanation of Robot Controller Safety Functions                | 9  |
| 2.2 Required Knowledge  | 12 |
| 2.2.1 Undergoing Training   | 12 |
| 2.2.2 Basic Knowledge of Epson RC+                                  | 12 |
| 2.3 Precautions for Using the Robot Controller Safety Functions     | 12 |
| 2.4 Terminology   | 14 |
| 2.5 System Configuration  | 15 |
| 3. Details of Robot Controller Safety Functions                     | 17 |
| 3.1 Main Functions  | 18 |
| 3.2 Safe Torque OFF (STO)   | 19 |
| 3.2.1 Outline and Operation Patterns for Safe Torque OFF (STO)      | 19 |
| 3.3 Safe Stop 1 (SS1)   | 20 |
| 3.3.1 Outline and Operation Patterns for Safe Stop 1 (SS1)          | 20 |
| 3.4 Emergency Stop  | 23 |
| 3.4.1 Outline and Operation Patterns for the Emergency Stop         | 23 |
| 3.5 Enable  | 24 |
| 3.5.1 Outline and Operation Patterns for Enable                     | 24 |
| 3.6 Safety Limited Speed (SLS)                                      | 25 |
| 3.6.1 Outline and Operation Patterns for Safety Limited Speed (SLS) | 25 |
| 3.6.2 Safety Limited Speed (SLS) for a SCARA Manipulator            | 27 |
| 3.6.3 Safety Limited Speed (SLS) for a 6-Axis Manipulator           | 29 |
|   |    |

| 3.7 Safety Limited Position (SLP)  | 31 |
|--|----|
| 3.7.1 Outline and Operation Patterns for Safety Limited Position (SLP)               | 31 |
| 3.7.2 Robot Monitoring Range for a SCARA Manipulator                                 | 33 |
| 3.7.3 Monitoring Areas for a SCARA Manipulator                                       | 34 |
| 3.7.4 Robot Monitoring Range for a 6-Axis Manipulator                                | 35 |
| 3.7.5 Monitoring Areas for a 6-Axis Manipulator                                      | 36 |
| 3.8 Joint Angle Limit  | 38 |
| 3.8.1 Outline and Operation Patterns for Joint Angle Limit                           | 38 |
| 3.8.2 Joint Angle Limit for the Manipulator  | 40 |
| 3.9 Soft Axis Limiting   | 42 |
| 3.9.1 Outline and Operation Patterns for Soft Axis Limiting                          | 42 |
| 3.9.2 Manipulator Operating Range  | 43 |
| 3.10 Safety Inputs   | 45 |
| 3.10.1 Outline and Operation Patterns for Safety Inputs                              | 45 |
| 3.11 Safety Outputs  | 49 |
| 3.11.1 Outline and Operation Patterns for Safety Outputs                             | 49 |
| 4. Setting Safety Functions (Setting Software: Safety Function Manager)              | 51 |
| 4.1 What is Safety Function Manager?   | 52 |
| 4.1.1 What Safety Function Manager Can Do  | 52 |
| 4.1.2 Operating Environment  | 52 |
| 4.1.3 Installation   | 52 |
| 4.1.4 How to Check the Version   | 52 |
| 4.1.5 Settable Items for Safety Function Options                                     | 54 |
| 4.2 Flow from Startup to Finish  | 55 |
| 4.2.1 Operation Flow   | 55 |
| 4.2.2 Starting Safety Function Manager   | 55 |
| 4.2.2.1 Checking Settings When Starting up Safety Function Manager                   | 56 |
| 4.2.3 Changing Settings  | 58 |
| 4.2.4 Applying Settings  | 60 |
| 4.2.5 Saving Settings (Performing a Backup)  | 61 |
| 4.2.6 Confirming Saved Information (Saved States Viewer)                             | 62 |
| 4.3 Safety Function Parameters   | 63 |
| 4.3.1 Setting Safety Function Parameters Related to Safety Inputs and Safety Outputs | 63 |
| 4.3.2 Setting Safety Function Parameters Related to Safety Limited Speed (SLS)       | 67 |
| 4.3.3 Robot Installation Position Settings for Safety Limited Position (SLP)         | 70 |

| 4.3.4 Setting Safety Limited Position (SLP)                           | 71  |
|---|-----|
| 4.3.5 Setting Soft Axis Limiting                                      |     |
| 4.3.6 SLP Viewer  |     |
| 4.3.7 Applying Safety Function Parameters                             | 80  |
| 4.4 Making Dry Run Settings   | 81  |
| 4.5 Outputting the Safety Function Parameters to Text                 | 82  |
| 4.6 Safety Board Maintenance  | 83  |
| 4.6.1 Restoring Factory Default Settings                              | 83  |
| 4.6.2 Changing the Safety Board Password                              | 84  |
| 4.6.3 Restoring Saved (Backed-up) Settings                            | 86  |
| 4.6.4 Set the Robot Settings of the Controller to the Safety Board    | 88  |
| 4.7 How to Reset the Robot When It Stopped due to a Safety Function   | 90  |
| 5. Example of Using Safety Functions                                  | 91  |
| 5.1 Environment Required to Check Operation                           | 92  |
| 5.2 Example of Using Safety Input Functions                           | 93  |
| 5.3 Example of Using Safety Output Functions                          | 97  |
| 5.4 Example of Using Safety Limited Speed (SLS)                       | 100 |
| 5.5 Example of Using Joint Angle Limit                                | 104 |
| 5.6 Example of Using Safety Limited Position (SLP)                    | 108 |
| 5.6.1 Safety Limited Position (SLP) Settings for a SCARA Manipulator  | 108 |
| 5.6.2 Safety Limited Position (SLP) Settings for a 6-Axis Manipulator | 110 |
| 5.6.3 Confirming the Operation of the Safety Limited Position (SLP)   | 113 |
| 5.7 Example of Using Soft Axis Limiting                               | 118 |

## 1. Introduction

## 1.1 Introduction

Thank you for purchasing this Epson robot system.

This manual provides the information necessary for correctly using the Robot Controller safety functions.

Before using the system, please read this manual and related manuals to ensure correct use.

After reading this manual, store it in an easily accessible location for future reference.

Epson conducts rigorous testing and inspection to ensure that the performance of our robot systems meets our standards. Please note that if the Epson robot system is used outside the operating conditions described in the manual, the product will not perform up to its basic performance.

This manual describes potential hazards and problems that are foreseen. To use the Epson robot system safely and correctly, be sure to follow the safety information contained in this manual.

## 1.2 Trademarks

Microsoft, Windows, the Windows logo, Visual Basic, and Visual C++ are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. All other company names, brand names, and product names are registered trademarks or trademarks of their respective companies.

#### 1.3 Notation

Microsoft® Windows® 10 operating system

Microsoft® Windows® 11 operating system

In this manual, the above operating systems are referred to as Windows 10 and Windows 11, respectively. Windows 10 and Windows 11 are sometimes collectively referred to as Windows.

## 1.4 Terms of Use

No part of this instruction manual may be reproduced or reprinted in any form without express written permission.

The information in this document is subject to change without notice.

Please contact us if you find any errors in this document or if you have any questions about the information in this document.

## 1.5 Manufacturer

#### SEIKO EPSON CORPORATION

### 1.6 Contact Information

Contact information details are listed in the "Supplier" section in the following manual.

Note that the contact information may vary depending on your region.

"Safety Manual - Contact Information"

The Safety Manual is also available at the following site.

URL: https://download.epson.biz/robots/



## 1.7 Before Use

Before using this manual, be sure that you understand the following information.

#### Safety precautions

Only qualified personnel should transport and install the robot and the related equipment. Also, the laws and regulations of the installation country must be followed.

Before use, please carefully read this manual and other related manuals to ensure correct use.

After reading this manual, store it in an easily accessible location for future reference.

#### Meaning of symbols



This symbol indicates an imminently hazardous situation which, if operation is not performed properly, will result in death or serious injury.

## **A** CAUTION

This symbol indicates a potentially hazardous situation which, if operation is not performed properly, may result in an injury or in property damage only.

## 1.8 Setting by Using Software

This manual contains setup procedures using the software.

Those sections are indicated by the following symbols.



## 1.9 Training

Personnel using the safety functions of the Robot Controller must undergo the "installation training" or "maintenance training" conducted by Epson. To ensure that our customers understand our products, Epson provides training on a regular or ad hoc basis.

Undergoing formal training will allow you to properly use the product and increase productivity. For details on training, please contact the supplier.

# 2. Overview of the Robot Controller Safety Functions

## 2.1 Explanation of Robot Controller Safety Functions

The Robot Controller safety functions can be used to set safety inputs and safety outputs, and to create applications that link to safety devices.

Also, the safety function options support functions that safely control the operating speed and operating range of the robot. You can set the robot's Maximum Speed and monitoring area to achieve an application for safely controlling the robot.

## **⚠** CAUTION

The safety performance of the Robot Controller safety functions is Category 3, PLd (Reference standard: ISO 13849-1).

Please ensure the safety of the robot system in light of the safety performance of the Robot Controller safety functions. Also, please refer to and observe the safety standards of the respective country and region.

The following describes the types and characteristics of the Robot Controller safety functions.

#### **Controller Safety Function standard functions:**

#### Safe Torque OFF (STO)

A signal input from the Robot Controller opens a relay to cut off the power supply to the motors and stop the robot. This is a safe state for the Robot Controller.

STO is operated indirectly from an emergency stop or protective stop. It will also operate when the Safety board detects abnormalities. It cannot operate directly.

#### Emergency Stop

This function allows the robot to perform an emergency stop by a signal input from a safety relay or from an emergency stop switch attached to the emergency stop input connector or safety I/O connector. After the signal is input, an SS1 is executed, and after the motor stops, the robot is in an emergency stop status. During the emergency stop status, EP is displayed on the 7-segment LED of the Robot Controller.

There are three emergency stop circuits for the Robot Controller:

- Emergency stop input connector (E-Stop)
- Port of the safety I/O connector configured for the emergency stop (Safety Input)
- Emergency stop switch attached to Teach Pendant (E-Stop, TP)

#### Safeguard (SG) (protective stop)

This function allows the robot to perform a protective stop by a signal input from a safety peripheral device attached to the safety I/O connector. After the signal is input, the SS1 is executed, and after the motor stops, the robot is in a protective stop status. SO is displayed on the 7-segment LED of the Robot Controller.

The Robot Controller safeguard (SG) circuit is as follow:

• Port of the safety I/O connector configured for the safeguard (SG)

#### Enable

Enable is the path connected to the enable switch when the Teach Pendant is connected. Only Epson Teach Pendants can be connected, and customer enable switches cannot be connected.

When the system detects that the enable switch of the Teach Pendant is not in the middle position, the SS1 is executed, and the robot is in an STO state.

#### Soft Axis Limiting

This monitors that each axis of the robot is within its operating range. If the system detects that an axis of the robot exceeded the limiting range, the robot emergency stop and STO are executed and the robot is stopped. For details on the

status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

Precautions for Using the Robot Controller Safety Functions

The restricted range for each axis of the robot is set in the dedicated software (Safety Function Manager).

#### Safety outputs

External safety devices can be connected to the safety outputs of the Robot Controller to perform notifications of the ON/OFF status of the safety functions.

By assigning settings in the dedicated software (Safety Function Manager), the following safety signals can be output:

- · STO state
- Status of the emergency stop switch
- Status of the enable switch
- Enabled/disabled status of the Safety Limited Speed (SLS)
- Enabled/disabled status of the Safety Limited Position (SLP)

#### **Controller Safety Function charged optional functions:**

#### Safety Limited Speed (SLS)

This monitors the operating speed of the robot. If the system detects that the robot exceeded the Maximum Speed, the robot emergency stop and STO are immediately executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

**Precautions for Using the Robot Controller Safety Functions** 

The safety speed limit of the robot is set in the dedicated software (Safety Function Manager).



The speed monitoring function during teaching can be used as a standard function.

#### Safety Limited Position (SLP)

This monitors the robot's position and joint angles. If the system detects that the robot exceeded the monitored areas or joint angle limit, the robot emergency stop and STO are immediately executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

Precautions for Using the Robot Controller Safety Functions

The Monitored Areas and Joint Angle Limit of the robot are set in the dedicated software (Safety Function Manager).

#### Reference

For details on each function, refer to the following sections.

#### Standard functions:

- Safe Torque OFF (STO)
- Safe Stop 1 (SS1)
- Emergency Stop
- Enable
- Soft Axis Limiting
- Safety Inputs
- Safety Outputs

#### Paid option functions:

- Safety Limited Speed (SLS)
- Safety Limited Position (SLP)
- Joint Angle Limit

## **ℰ** KEY POINTS

For details on the "Safety Function Manager," refer to the following section.

**Setting Safety Functions (Setting Software: Safety Function Manager)** 

## 2.2 Required Knowledge

## 2.2.1 Undergoing Training

Personnel using the safety functions of the Robot Controller must undergo the "installation training" or "maintenance training" conducted by Epson.

## 2.2.2 Basic Knowledge of Epson RC+

Use of the safety functions of the Robot Controller requires knowledge of the software used to develop programs for the Robot Controller, Epson RC+, as well as Epson robots. The contents of this manual are intended for persons who are knowledgeable about the following:

- Concept of Epson RC+ project management, and how to use it
- How to create and edit SPEL+ programs in Epson RC+
- How to execute the SPEL+ program from the Run window
- Basic language structure and functionality of SPEL+, and how to use it

## **№** KEY POINTS

Personnel using Epson RC+ for the first time must undergo the "installation training" conducted by Epson.

## 2.3 Precautions for Using the Robot Controller Safety Functions

When using the Robot Controller safety functions, follow the safety precautions described below.

## **⚠** WARNING

- Be sure to check the safety function parameter settings when operating a Robot Controller in its initial state or when operating a Robot Controller with unknown safety function parameter settings. Also, operate the Manipulator after understanding the operation of the safety functions.
- Be sure to check that the intended operation is achieved when changing from the previous state of use, such as when safety function parameters are changed or when parts are replaced for maintenance.
- When checking operation, use low power mode.
   Reducing the motor output ensures operator safety and reduces the risk of destruction and damage to peripheral equipment due to careless operation.
- Before beginning full operation, check that the safety function parameters are set as intended.
  - The parameter checksum of the safety functions is calculated from the safety function parameters. If the parameter checksum of the safety functions is changed, it means that the safety function parameters have been changed. Incorrectly set safety functions may cause serious safety problems.
- Before beginning full operation, make sure that the safety devices such as the emergency stop switch and safeguard switch operate. Operation without the switches functioning properly may result in the safety functions failing to operate during an emergency, which is extremely hazardous and may result in serious injury to operators and/or severe equipment damage.

 RC700-E and RC800 series differ in stopping behavior due to safety functions (safety limited speed (SLS), safety limited position (SLP), joint angle limit, and soft axis limiting). The status, display, and notifications for each Robot Controller are as shown in the following table.

| Item   | RC700-E  | RC800 sereis   |
|--|--|--|
| Robot Controller<br>7-segment LED<br>display | Display as (-EP-) (EP) <sup>※3</sup>   | Display error number 4-digit error number (0.5 second) and (EEEE) are displayed (0.5 second) repeatedly          |
| How to stop                                  | Emergency stop (stop category 1)   | Emergency stop (stop category 1)   |
| How to reset                                 | After solving all the problems that caused the robot to stop, reset the Controller <sup>×1</sup> | After solving all the problems that caused the robot to stop, reset the Controller <sup>※1</sup>                 |
| How to check why<br>the robot has<br>stopped | Refer to the note information for events 27 and 28 in the system history <sup>**2</sup>          | Refer to error number or refer to the note information for events 27 and 28 in the system history <sup>**2</sup> |
| Robot Controller<br>Status                   | Emergency stop status <sup>※3</sup>  | Error status   |

X1 Refer to the following section.

#### How to Reset the Robot When It Stopped due to a Safety Function

- ※2 Refer to the following manual.
- "Epson RC+ User's Guide [System History] (View Menu)"
- "Status Code/Error Code List Code Number, Details of Note Information"

\*3 The robot is in an emergency stop status only when the motor is on. In the event of a Motor Off status, turning on the motor will result in an error unless you eliminate the cause of the motor stopping.

## 2.4 Terminology

#### Safety device

This refers to a device that is connected to a safety I/O connector of the Robot Controller.

#### Dry run

This refers to the status when a Robot Controller that is not connected to a Manipulator is used to check the operation of the robot program.

#### **Operation mode**

This refers to either AUTO mode (including PROGRAM mode), TEACH mode, TEST T1 mode, or TEST T2 mode. This can be changed using the Teach Pendant.

#### Hofs

This refers to the offset value of the robot's joint axes.

#### Safety board

This refers to the board for monitoring the robot system.

It is built into the Robot Controller.


#### Tool coordinate tip point (TCP)

This refers to the point of contact between the hand and the workpiece. Set this according to the hand.

## 2.5 System Configuration

Safety devices can be connected to the safety I/O connectors of the Robot Controller.

- 1. Connect the safety outputs of safety devices to the safety inputs of the safety I/O connectors.
- 2. Connect the safety inputs of safety devices to the safety outputs of the safety I/O connectors.



Example of system configuration using the Robot Controller safety functions:

## **ℰ** KEY POINTS

For details on how to connect safety devices and the Robot Controller, refer to the following manual.

"Robot Controller RC700-E Manual"

"Robot Controller RC800-A Manual"

"Robot Controller RC800L Manual"

Each safety function can be used in the following operating environment.

| Manipulator     | Controller | Application                                |                       | Safety board firmware      |  |
|-----------------|------------|--|-----------------------|----------------------------|--|
| iviarripulator  | Controller | RC+8.0                                     | RC+7.0                | Salety board liffiware     |  |
| GX4-B/GX8-B     |            |  | Ver.7.5.4 or later    |                            |  |
| GX10-B/GX20-B   | RC700-E    |  | Ver.7.5.4A or later   | Rel.02.00.00.0033 or later |  |
| C4-B/C8-B/C12-B |            | Ver.8.0.0 or later                         | Ver.7.5.4C or later   |                            |  |
| GX4-C/GX8-C     |            |  |                       | Rel.02.01.00.0009 or late  |  |
| GX10-C/GX20-C   |            |  |                       | Kei.02.01.00.0009 of fater |  |
| GX1-C           | RC800-A    | Ver.8.0.0.2 or later  Ver.8.1.0.4 or later | *                     | Rel.02.03.00.0013 or later |  |
| C8-C/C12-C      |            |  | Not available for use | Rel.02.01.00.0009 or later |  |
| LS50-C          |            |  |                       | Rel.02.03.00.0013 or later |  |
| LA3-A/LA6-A     | RC800L     | ve1.6.1.0.4 01 late1                       |                       | Rel.02.03.00.0016 or later |  |

For the safety board's firmware version, refer to the following section.

**How to Check the Version** 

# 3. Details of Robot Controller Safety Functions

## 3.1 Main Functions

Refer to the following section for details.

#### **Explanation of Robot Controller Safety Functions**

For details on each function, refer to the following sections.

#### **Standard functions:**

- Safe Torque OFF (STO)
- Safe Stop 1 (SS1)
- Emergency Stop
- Enable
- Soft Axis Limiting
- Safety Inputs
- Safety Outputs

#### Paid option functions:


- Safety Limited Speed (SLS)
- Safety Limited Position (SLP)
- **Joint Angle Limit**

## 3.2 Safe Torque OFF (STO)

## 3.2.1 Outline and Operation Patterns for Safe Torque OFF (STO)

Safe Torque OFF (STO) is a function that opens the relay and disconnects the power supply to the motors when a monitoring value of a safety function is exceeded.

Safe Torque OFF (STO) is equivalent to stop category 0. (Reference standard: IEC 60204-1)



## 3.3 Safe Stop 1 (SS1)


## 3.3.1 Outline and Operation Patterns for Safe Stop 1 (SS1)

Safe Stop 1 (SS1) is a function that monitors whether the robot decelerates and stops normally when there is an emergency stop or a protective stop. If an abnormal deceleration of TCP speed is detected during stop control, Safe Torque OFF (STO) is immediately executed.

Safe Stop 1 is equivalent to stop category 1. (Reference standard: IEC 60204-1)


#### Relationship between Safe Stop 1 (SS1) and the STO statement (normal state)

If stop control is normal, Safe Torque OFF (STO) is executed after stop control is completed.




## Relationship between Safe Stop 1 (SS1) and the STO statement (when deceleration abnormality is detected)

If an abnormal deceleration of TCP speed is observed during stop control, Safe Torque OFF (STO) is immediately executed.



#### Relationship between Safe Stop 1 (SS1) and the STO statement (after the monitoring time)

If the TCP speed does not decelerate to 1 [mm/sec] or less even after a certain period of time from the start of stop control, Safe Torque OFF (STO) is immediately executed.




## 3.4 Emergency Stop

## 3.4.1 Outline and Operation Patterns for the Emergency Stop

When the emergency stop switch is turned ON (is pressed), Safe Stop 1 (SS1) is executed and then Safe Torque OFF (STO) is executed, putting the Robot Controller in the emergency stop status.

#### Relationship between the emergency stop and the STO statement




## 3.5 Enable

## 3.5.1 Outline and Operation Patterns for Enable

When the enable switch is OFF (is in a position other than the middle position), Safe Stop 1 (SS1) is executed and then Safe Torque OFF (STO) is executed, performing a protective stop.

#### Relationship between Enable and the STO statement



## 3.6 Safety Limited Speed (SLS)

## 3.6.1 Outline and Operation Patterns for Safety Limited Speed (SLS)

Safety Limited Speed (SLS) is a function that monitors the robot's operating speed. If, during operation, the robot exceeds the Maximum Speed, Safe Torque OFF (STO) is immediately executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

**Precautions for Using the Robot Controller Safety Functions** 

## **MARNING**

Please set the Maximum Speed considering the stopping distance. For the stopping distance, refer to the following manual.

"Manipulator Manual - Appendix B: Stopping Time and Stopping Distance at Emergency Stop"

#### Operation modes and enabling/disabling Safety Limited Speed (SLS)

When the operation mode is TEACH or TEST T1, the Safety Limited Speed pattern SLS\_T is always enabled. Safety Limited Speed SLS\_T is a standard function.

When the operation mode is TEST T2, the Safety Limited Speed pattern SLS\_T2 is always enabled. Safety Limited Speed pattern SLS\_T2 is a standard function.

When the operation mode is AUTO, TEST T1, or TEST T2, the safety inputs can be used to enable or disable Safety Limited Speed (SLS). In these operation modes, three patterns of Maximum Speeds, SLS\_1, SLS\_2, and SLS\_3, can be set. Safety Limited Speed patterns SLS\_1, SLS\_2, and SLS\_3 are safety function options.

| Safety Limited Speed (SLS) patterns |        | Enable or disable for each operation mode A: Always enable B: Enable or disable based on safety inputs -: Always disable |       |         |         |
|-------------------------------------|--------|--|-------|---------|---------|
|                                     |        | AUTO   | TEACH | TEST T1 | TEST T2 |
| Standard functions                  | SLS_T* | -  | A     | A       | -       |
|                                     | SLS_T2 | -  | -     | -       | A       |
| Optional safety functions           | SLS_1  | В  | -     | В       | В       |
|                                     | SLS_2  | В  | -     | В       | В       |
|                                     | SLS_3  | В  | -     | В       | В       |

<sup>\*:</sup> For details on the Safety Limited Speed pattern SLS\_T, refer to the following section.


- Safety Limited Speed (SLS) for a SCARA Manipulator
- Safety Limited Speed (SLS) for a 6-Axis Manipulator

#### Relationship between Safety Limited Speed (SLS) and the STO statement

If, during robot operation, the system detects that the Maximum Speed was exceeded, Safe Torque OFF (STO) is immediately executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by

the safety function, refer to the following.

#### **Precautions for Using the Robot Controller Safety Functions**



## 3.6.2 Safety Limited Speed (SLS) for a SCARA Manipulator


When using Safety Limited Speed (SLS) for a SCARA Manipulator, there are six locations that are monitored at the Maximum Speed. The speed (rotation or up/down) of each joint is expressed as a percentage of the maximum speed (rotation or up/down) of that joint. For the 3 Axis specification, there are five locations that are monitored at the Maximum Speed, excluding each speed (rotation) [%] for Joint #4.

- Speed (rotation) at Joints #1, #2, and #4 [%]
- Speed (up/down) of Joint #3 (ball screw linear motion mechanism) [%]
- Speed at Joint #2 (translation) [mm/sec]
- TCP speed [mm/sec]


The TCP offset from the tip of the ball screw linear motion mechanism to the TCP is set in Safety Function Manager. With Safety Limited Speed (SLS) using the Safety Limited Speed pattern SLS\_T, the TCP speed and Joint #2 speed (translation) limit is 250 [mm/sec].

## **CAUTION**

The TCP offset setting set in Safety Function Manager is not linked to the setting parameters set in the "Tool Settings" section of the "Epson RC+ User's Guide". Make sure that these settings are consistent.



The  $X,\,Y,\,$  and Z standards for the TCP offset are the Tool 0 coordinate system in Epson RC+.




## 3.6.3 Safety Limited Speed (SLS) for a 6-Axis Manipulator


When using Safety Limited Speed (SLS) for a 6-Axis Manipulator, there are 10 locations that are monitored at the Maximum Speed. The rotation speed of each joint is expressed as a percentage of the maximum rotation speed of the corresponding joint.

- Speed at Joint (rotation) #1 to #6 [%]
- Speed at Joint #2 (translation) [mm/sec]
- Speed at Joint #3 (translation) [mm/sec]
- Speed at Joint #5 (translation) [mm/sec]
- TCP speed [mm/sec]

The TCP offset from the tip of Joint #6 to the TCP is set in Safety Function Manager. With Safety Limited Speed (SLS) using the Safety Limited Speed pattern SLS\_T, the TCP speed and Joint #2, Joint #3, and Joint #5 speed (translation) limit is 250 [mm/sec].



The X, Y, and Z standards for the TCP offset are the Tool 0 coordinate system in Epson RC+. For table top mounting, this is as follows.



For details on the Tool 0 coordinate system for a celling mounting or wall mounting, refer to the following manual.

<sup>&</sup>quot;Epson RC+ User's Guide - Tool Coordinate System"

## 3.7 Safety Limited Position (SLP)

## 3.7.1 Outline and Operation Patterns for Safety Limited Position (SLP)

Safety Limited Position (SLP) is a function that monitors the robot's operating position. If the system detects that, during robot operation, the robot monitored range has entered the monitored area, then Safe Torque OFF (STO) is immediately executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

**Precautions for Using the Robot Controller Safety Functions** 

Safety Limited Position (SLP) is a safety function option.

## **WARNING**

Please set the motion range considering the stopping distance. For the stopping distance, refer to the following manual.

"Manipulator Manual - Appendix B: Stopping Time and Stopping Distance at Emergency Stop"

• If the robot speed is limited by the Safety Limited Speed (SLS), the restricted area can be determined based on the stopping distance calculated from the speed set by the Safety Limited Speed (SLS). If you are not using the Safety Limited Speed (SLS) function, determine the restricted area considering the stopping distance calculated from the robot's maximum speed.

#### Operation modes and enabling/disabling Safety Limited Position (SLP)

When the operation mode is AUTO, TEST T1, or TEST T2, the safety inputs can be used to enable or disable the Monitored Areas and Joint Angle Limit.

## KEY POINTS

- For details on monitoring area, refer to the following section.
  - Monitoring Areas for a SCARA Manipulator
  - Monitoring Areas for a 6-Axis Manipulator
- For details on the Joint Angle Limit, refer to the following section.

**Joint Angle Limit** 


When the operation mode is TEACH, Safety Limited Position (SLP) is always disabled.

| Safety Limited Position (SLP) patterns |       | Enable or disable for each operation mode B: Enable or disable based on safety inputs -: Always disable |       |         |         |
|--|-------|---|-------|---------|---------|
|  |       | AUTO  | TEACH | TEST T1 | TEST T2 |
|  | SLP_A | В   | -     | В       | В       |
| Optional safety functions              | SLP_B | В   | -     | В       | В       |
|  | SLP_C | В   | -     | В       | В       |

#### Relationship between Safety Limited Position (SLP) and the STO statement

If the system detects that, during robot operation, the robot monitored range has exceeded the monitored area, then Safe Torque OFF (STO) is immediately executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.


**Precautions for Using the Robot Controller Safety Functions** 




## 3.7.2 Robot Monitoring Range for a SCARA Manipulator

The robot monitoring ranges for the Safety Limited Position of a SCARA Manipulator are in two locations: a circle centered on Joint #2 (J2, Robot Monitored Range 1) and a circle centered on Joint #3 (J3, Robot Monitored Range 2). These robot monitoring ranges are set in Safety Function Manager. The minimum values that can be set are defined by the type of Manipulator.

Safety Limited Position (SLP) monitors whether the set monitoring range exceeds the Monitored Areas set by the coordinate system in which the robot is installed.




With Safety Limited Position (SLP) of a SCARA Manipulator, the robot installation position offset  $(X_{ofs}, Y_{ofs})$  in the robot coordinate system  $X_R$ - $Y_R$  and the robot installation plane rotation  $U_{rot}$  are set based on the coordinate system  $X_W$ - $Y_W$  where the robot is installed.



## 3.7.3 Monitoring Areas for a SCARA Manipulator

The monitoring areas for a SCARA Manipulator are specified within the restricted range of a  $X_W$ - $Y_W$  plane in the coordinate system  $X_W$ - $Y_W$  where the robot with Safety Limited Position is installed. There are 16 configurable restricted range patterns, (a) through (p).


These monitored areas are set as the positions  $(X_1, 0)$ ,  $(X_2, 0)$ ,  $(0, Y_1)$ ,  $(0, Y_2)$  that intersect with the coordinate system  $X_W$ - $Y_W$  where the robot is installed. The robot monitoring range is monitored to ensure that it does not enter the monitoring areas.




## 3.7.4 Robot Monitoring Range for a 6-Axis Manipulator

The robot monitoring ranges for the Safety Limited Position of a 6-Axis Manipulator are in four locations: a sphere centered on Joint #2 (J2, Robot Monitored Range 1), a sphere centered on Joint #3 (J3, Robot Monitored Range 2), a sphere centered on Joint #5 (J5, Robot Monitored Range 3), and a sphere centered on Joint #6 (J6, Robot Monitored Range 4). These robot monitoring ranges are set in Safety Function Manager. The minimum values that can be set are defined by the type of Manipulator.

Safety Limited Position (SLP) monitors whether the set monitoring range exceeds the Monitored Areas set by the coordinate system in which the robot is installed.




With Safety Limited Position (SLP) of a 6-Axis Manipulator, the robot installation position offset  $(X_{ofs}, Y_{ofs}, Z_{ofs})$  in the robot coordinate system  $X_R$ - $Y_R$ - $Z_R$  and the robot installation plane rotation  $(U_{rot}, V_{rot}, W_{rot})$  are set based on the coordinate system  $X_W$ ,  $Y_W$ - $Z_W$  where the robot is installed.




## 3.7.5 Monitoring Areas for a 6-Axis Manipulator

The monitoring areas for a 6-Axis Manipulator are specified based on a combination of the restricted range pattern of a  $X_W$ - $Y_W$  plane and the restricted range pattern in the  $Z_W$  direction in the coordinate system  $X_W$ - $Y_W$ - $Z_W$  where the robot with Safety Limited Position is installed. There are 16 configurable restricted range patterns on a  $X_W$ - $Y_W$  plane, (a) through (p). These monitored areas are set as the positions  $(X_1, 0)$ ,  $(X_2, 0)$ ,  $(0, Y_1)$ ,  $(0, Y_2)$  that intersect with the coordinate system  $X_W$ - $Y_W$  where the robot is installed. The robot monitoring range is monitored to ensure that it does not enter the monitoring areas.



There are three configurable restricted range patterns in the  $Z_W$  direction, (q) through (s). These monitored areas are set as the positions ( $Z_1$ ,  $Z_2$ ) in the  $Z_W$  direction in the coordinate system where the robot is installed. The robot monitoring range is monitored to ensure that it does not enter the monitoring areas.



## 3.8 Joint Angle Limit

## 3.8.1 Outline and Operation Patterns for Joint Angle Limit

Joint Angle Limit is a function that monitors the robot's joint angles. If the system detects that the robot exceeded the motion range, Safe Torque OFF (STO) is immediately executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

**Precautions for Using the Robot Controller Safety Functions** 

Joint Angle Limit is a safety function option.

#### Operation modes and enabling/disabling Joint Angle Limit

When the operation mode is AUTO, TEST T1, or TEST T2, patterns\* that use the narrow range based on the rotation angle or vertical movement of an axis of the robot as the operating range can be assigned.

\*: When using SLS\_1 as the Joint Angle Limit

When the operation mode is TEACH, Joint Angle Limit is always disabled.


| Joint Angle Limit Pa      | Joint Angle Limit Pattern |                       | Enable or disable for each operation mode B: Enable or disable based on safety inputs -: Always disable |         |   |  |
|---------------------------|---------------------------|-----------------------|---|---------|---|--|
|                           |                           | AUTO TEACH TEST T1 TE |   | TEST T2 |   |  |
| Optional safety functions | SLS_1 *                   | В                     | -   | В       | В |  |

<sup>\*:</sup> Case where a pattern setting the narrow range based on the rotation angle or vertical movement of an axis of the robot as the operating range for monitoring is assigned to SLS\_1.

#### Relationship between Joint Angle Limit and the STO statement


If the system detects that either the rotation angle or vertical movement of an axis of the robot exceeded the motion range, Safe Torque OFF (STO) is immediately executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

**Precautions for Using the Robot Controller Safety Functions** 




#### 3.8.2 Joint Angle Limit for the Manipulator

With a SCARA Manipulator, Joint #1 (rotation), Joint #2 (rotation), Joint #3 (up/down), and Joint #4 (rotation) are all subject to the Joint Angle Limit, which sets the narrow range based on the rotation angle or vertical movement of an axis of the robot as the operating range. For the 3-Axis specification, there are three locations that are monitored at the Joint Angle Limit, excluding Joint #4 (rotation).



With a 6-Axis Manipulator, Joint #1 (rotation), Joint #2 (rotation), Joint #3 (rotation), Joint #4 (rotation), Joint #5 (rotation), and Joint #6 (rotation) are all subject to the Joint Angle Limit, which sets the narrow range based on the rotation angle of an axis of the robot as the operating range.



## 3.9 Soft Axis Limiting

## 3.9.1 Outline and Operation Patterns for Soft Axis Limiting

Soft Axis Limiting is a function that monitors the robot's joint operating range. If the system detects that either the rotation angle or vertical movement of an axis of the robot exceeded the motion range of an axis, the robot emergency stop and STO are executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

**Precautions for Using the Robot Controller Safety Functions** 

#### Operation modes and enabling/disabling Soft Axis Limiting

When the operation mode is AUTO, TEST T1, or TEST T2, Soft Axis Limiting is always enabled.


When the operation mode is TEACH, Soft Axis Limiting is always disabled.

| Soft Axis Limiting | Enable or disable for each operation mode A: Always enable -: Always disable |       |         |         |
|--------------------|--|-------|---------|---------|
|                    | AUTO   | TEACH | TEST T1 | TEST T2 |
| Standard functions | A  | -     | A       | A       |

#### Relationship between Soft Axis Limiting and the STO statement


If the system detects that either the rotation angle or vertical movement of an axis of the robot exceeded the motion range, the robot emergency stop and STO are immediately executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

#### **Precautions for Using the Robot Controller Safety Functions**




#### 3.9.2 Manipulator Operating Range

With a SCARA Manipulator, Joint #1 (rotation), Joint #2 (rotation), Joint #3 (up/down), and Joint #4 (rotation) are all subject to monitoring by Soft Axis Limiting. For the 3-Axis specification, Joint #4 is not subject to monitoring.



With a 6-Axis Manipulator, Joint #1 (rotation), Joint #2 (rotation), Joint #3 (rotation), Joint #4 (rotation), Joint #5 (rotation), and Joint #6 (rotation) are all subject to monitoring by Soft Axis Limiting.



The rotation angle or motion range for vertical motion of an axis of the robot can be set to a value at or below the pulse range set for each robot model. For details on the configurable pulse range, refer to the following manual.

"Manipulator Manual - Operation Area Settings"


Motion range settings are made in Safety Function Manager.




#### CAUTION

The operating range set in Safety Function Manager is not linked to the setting parameters set in the "Tool Settings" section of the "Epson RC+ User's Guide". Make sure that these settings are consistent.

#### When using the mechanical stop and Soft Axis Limiting together



#### When using only Soft Axis Limiting



## 

- When designing a robot system and restricting the robot motion area, perform restrictions using Soft Axis Limiting or the mechanical stop. However, due to robot safety standard requirements, a single-axis mechanical stop cannot be replaced by Soft Axis Limiting. For details on restriction using a mechanical stop, refer to the following manual.
  - "Manipulator Manual"
- If the robot speed is limited by the Safety Limited Speed (SLS), the restricted area can be determined based on the stopping distance calculated from the speed set by the Safety Limited Speed (SLS). If you are not using the Safety Limited Speed (SLS) function, determine the restricted area considering the stopping distance calculated from the robot's maximum speed.
- When using the mechanical stop and Soft Axis Limiting together, there is no need to set the motion range considering the stopping distance, because the mechanical stop is the limit.
- If using only the Soft Axis Limiting, set the motion range considering the stopping distance. For the stopping distance, refer to the following manual.
  - "Manipulator Manual Appendix B: Stopping Time and Stopping Distance at Emergency Stop"

## 3.10 Safety Inputs

#### 3.10.1 Outline and Operation Patterns for Safety Inputs

The safety inputs are functions that execute safety functions assigned to the safety inputs according to the output signal of the safety device connected to the safety inputs of safety I/O connectors.

The safety I/O connectors have five ports for safety inputs.

The safety functions that can be assigned to the safety inputs are as follows:

- Emergency Stop (ESTOP)
- Safeguard (SG)
- Safety Limited Speeds (SLS) SLS\_1, SLS\_2, and SLS\_3
  Refer to the following section for details.
   Safety Limited Speed (SLS)
- Safety Limited Positions (SLP) SLP\_A, SLP\_B, SLP\_C, and SLS\_1\*
   Refer to the following section for details.
   Safety Limited Position (SLP)

#### Operation modes and enabling/disabling safety inputs

Emergency Stop (ESTOP) can be executed in any operation mode. Safeguard (SG) can be executed in the AUTO operation mode.

| Safe Stop 1 by Safety Input 1 |       | Enable or disable for each operation mode B: Enable or disable based on safety inputs -: Always disable |       |         |         |
|-------------------------------|-------|---|-------|---------|---------|
|                               |       | AUTO  | TEACH | TEST T1 | TEST T2 |
| Standard functions            | ESTOP | В   | В     | В       | В       |
| Standard functions            | SG    | В   | -     | -       | -       |

Multiple safety functions can be assigned to a single safety input port. Multiple safety functions are prioritized in the following order:


- Priority: High Emergency Stop (ESTOP) Safeguard (SG)
- Priority: Low
   Safety Limited Speed (SLS)
   Safety Limited Position (SLP)
   Joint Angle Limit

<sup>\*:</sup> Case where Joint Angle Limit is enabled in SLS\_1 settings. Refer to the following section for details. **Joint Angle Limit** 

#### Relationship between safety inputs and the STO statement (when ESTOP or SG is assigned)

Safety inputs to which the Emergency Stop (ESTOP) or Safeguard (SG) are assigned execute Safe Stop 1 (SS1) when the signal level is "Low."

| Safety Input Signal Level | Safety Function Operation          |
|---------------------------|------------------------------------|
| High                      | Does not execute Safe Stop 1 (SS1) |
| Low                       | Executes Safe Stop 1 (SS1)         |




#### Relationship between safety inputs and the STO statement (when SLS is assigned)

The safety input to which Safety Limited Speed (SLS) is assigned disables Safety Limited Speed (SLS) when the signal level is "High" and enables Safety Limited Speed (SLS) when the signal level is "Low."

The delay time for enabling/disabling Safety Limited Speed (SLS) is set in Safety Function Manager.


| Safety Input Signal Level | Safety Function Operation           |
|---------------------------|-------------------------------------|
| High                      | Disables Safety Limited Speed (SLS) |
| Low                       | Enables Safety Limited Speed (SLS)  |



#### Relationship between safety inputs and the STO statement (when SLP is assigned)

The safety input to which Safety Limited Position (SLP) is assigned disables Safety Limited Position (SLP) when the signal level is "High" and enables Safety Limited Position (SLP) when the signal level is "Low."

| Safety Input Signal Level | Safety Function Operation              |  |
|---------------------------|--|--|
| High                      | Disables Safety Limited Position (SLP) |  |
| Low                       | Enables Safety Limited Position (SLP)  |  |



## 3.11 Safety Outputs

## 3.11.1 Outline and Operation Patterns for Safety Outputs

Safety outputs are functions that output information related to the safety functions of the Robot Controller to the safety devices connected to the safety outputs of the safety I/O connectors.

The Robot Controller has three ports for safety outputs.

The information that can be assigned to safety outputs is as follows:

- Whether the STO statement is being issued or not
- Whether the emergency stop switch is On or Off (emergency stop switch connected to the EMERGENCY connector, emergency stop switch attached to Teach Pendant)
- Whether the enable switch is on or off
- Whether Safety Limited Speed (SLS) is enabled or disabled (SLS\_1, SLS\_2, SLS\_3, SLS\_T, and SLS\_T2)
- Whether Safety Limited Position (SLP) is enabled or disabled (SLP\_A, SLP\_B, and SLP\_C)

Multiple pieces of information related to safety functions can be assigned to a single safety output port. When making multiple assignments, the signal level of the safety outputs becomes Low if the STO statement is issued (signal level is Low), the emergency stop is turned on (signal level is Low), the enable switch is turned off (signal level is Low), the Safety Limited Speed (SLS) is enabled (signal level is Low), or the Safety Limited Position (SLP) is enabled (signal level is Low).

#### Safety output status and output signal level

The safety output to which whether the STO statement is being issued or not is assigned outputs a signal on the Low level if the STO statement is being issued, and a signal on the High level if the STO statement is not being issued.

| Assignment to Safety   | y Outputs | uts Output Signal Level    |                        |
|------------------------|-----------|----------------------------|------------------------|
| STO Stateme            | ent       | High                       | Low                    |
| Standard functions STO |           | Statement not being issued | Statement being issued |

The safety output to which whether the emergency stop switch is on or off is assigned outputs a signal on the Low level if the switch is on, and a signal on the High level if the switch is off.

| Assignment to Safe | ty Outputs | Output Signal Level |           |  |
|--------------------|------------|---------------------|-----------|--|
| Emergency Stop     | Switch     | High                | Low       |  |
| Standard functions | EP_RC *    | Switch off          | Switch on |  |
| Standard functions | EP_TP*     | Switch off          | Switch on |  |

<sup>\*:</sup> EP\_RC: Emergency stop switch connected to the EMERGENCY connector, EP\_TP: Emergency stop switch attached to Teach Pendant

The safety output to which whether the enable switch is on or off is assigned outputs a signal on the Low level if the switch is off, and a signal on the High level if the switch is on.

| Assignment to Safety Outputs |       | Output Signal Level         |                                     |
|------------------------------|-------|-----------------------------|-------------------------------------|
| Enable Switch                |       | High                        | Low                                 |
| Standard functions           | EN_SW | Switch on (Middle position) | Switch off<br>(Not middle position) |

## **⚠** CAUTION

SLS and SLP output whether the monitoring function is enabled.

The signal does not switch even if the Manipulator exceeds speed limits or enters a restricted area. Therefore, to make a trigger when the Manipulator exceeds speed limits or enters a restricted area, use the STO output signal as well.

The safety output to which whether the Safety Limited Speed (SLS) is enabled or disabled is assigned outputs a signal on the Low level if the Safety Limited Speed (SLS) is enabled, and a signal on the High level if it is disabled.


| Assignment to Safety Outputs |        | Output Signal Level |                    |
|------------------------------|--------|---------------------|--------------------|
| Safety Limited Speed         | (SLS)  | High                | Low                |
| Standard functions           | SLS_T  | Limitation disabled | Limitation enabled |
| Standard functions           | SLS_T2 |                     |                    |
|                              | SLS_1  |                     | Limitation enabled |
| Optional safety functions    | SLS_2  | Limitation disabled |                    |
|                              | SLS_3  |                     |                    |

The safety output to which whether the Safety Limited Position (SLP) is enabled or disabled is assigned outputs a signal on the Low level if the Safety Limited Position (SLP) is enabled, and a signal on the High level if it is disabled.

| Assignment to Safety 0    | Outputs | Output Signal Level |                    |
|---------------------------|---------|---------------------|--------------------|
| Safety Limited Position   | (SLP)   | High                | Low                |
| Optional safety functions | SLP_A   | Limitation disabled | Limitation enabled |
|                           | SLP_B   |                     |                    |
|                           | SLP_C   |                     |                    |

#### Time from safety function information input until safety output signal is issued

Input signal level of the safety function information



# 4. Setting Safety Functions (Setting Software: Safety Function Manager)

## 4.1 What is Safety Function Manager?

#### 4.1.1 What Safety Function Manager Can Do

Safety Function Manager allows you to check and change the following settings related to Robot Controller safety functions:

Making dry run settings

Refer to the following section for details.

Making Dry Run Settings

- Checking the robot model, Hofs data, and safety board setting change dates
- Checking and changing safety function parameters (Robot Controller safety function parameters)
- Changing the password for the safety board

The language displayed is automatically switched according to the language of Epson RC+.

## **MARNING**

If you change the safety parameters for a safety function in the Safety Function Manager, be sure to verify that function and check its validity before use.

#### 4.1.2 Operating Environment

The Safety Function Manager can be used in the following environment.

**System Configuration** 

#### 4.1.3 Installation

Safety Function Manager is installed automatically when installing Epson RC+.


For the supported versions of Epson RC+, refer to the following section.

**System Configuration** 

#### 4.1.4 How to Check the Version

You can check the versions of Safety Function Manager and the safety board firmware.

Select the [Version Info] tag and check the displayed versions.



## 4.1.5 Settable Items for Safety Function Options

Some of the settings in Safety Function Manager are safety function options. Please contact the supplier if you require safety function options.

- √ : Available for use
- -: Not available for use

| Setting                       |  | Standard Functions   | Safety Function Options |
|-------------------------------|--|--|-------------------------|
| Dry Run Settings              | -  | ✓  | ✓                       |
| Safety Inputs                 | ESTOP<br>SG<br>SLS_1<br>SLS_2<br>SLS_3<br>SLP_A<br>SLP_B<br>SLP_C      | <ul><li></li><li>-</li><li>-</li><li>-</li><li>-</li><li>-</li></ul> | ✓                       |
| Safety Outputs                | STO EP_RC EP_TP EN_SW SLS_T SLS_T2 SLS_1 SLS_2 SLS_3 SLP_A SLP_B SLP_C | <pre></pre>  | ✓                       |
| Safety Limited Speed (SLS)    | SLS_T<br>SLS_T2<br>SLS_1<br>SLS_2<br>SLS_3                             | <ul><li></li><li>-</li><li>-</li><li>-</li></ul>                     | ✓                       |
| Safety Limited Position (SLP) | SLP_A<br>SLP_B<br>SLP_C<br>SLS_1 *                                     | -  | ✓                       |
| Soft Axis Limiting            | -  | ✓  | ✓                       |
| Factory Settings              | -  | V  | ✓                       |
| Password Management           | -  | ✓  | ✓                       |

<sup>\*:</sup> Case where Joint Angle Limit is enabled in SLS\_1 settings.

## 4.2 Flow from Startup to Finish

#### 4.2.1 Operation Flow

Changes to the safety function parameters of the safety board are performed as follows:

 Start "Safety Function Manager" Refer to the following section for details.

**Starting Safety Function Manager** 

2. Change settings

Refer to the following section for details.

**Changing Settings** 


3. Apply settings

Refer to the following section for details.

**Applying Settings** 

## 4.2.2 Starting Safety Function Manager

In Epson RC+, select [Setup] - [System Configuration], and then under [Controller] - [Safety Functions], click [Safety Function Manager].



#### **ℰ** KEY POINTS

- Safety Function Manager must be started for the first time by the safety manager.
- The following dialog box appears when starting up for the first time. Follow the on-screen instructions and change the safety board password. The initial password is "EpsonSafety".




- The display language of Safety Function Manager is automatically switched according to the language set in the Epson RC+.
- If you cannot perform startup, check the following conditions:
  - A Robot Controller equipped with safety functions must be connected.
  - The Epson RC+ start mode must be in program mode.
  - The control device for the Robot Controller must be a PC.

#### 4.2.2.1 Checking Settings When Starting up Safety Function Manager

When starting up Safety Function Manager, in the [Basic Settings] tab, check the settings of the safety board and make sure that they are the same as those of the Robot Controller.

It is recommended to keep a record of the [Parameter Checksum] of [Robot] and the [Parameter Checksum] of [Safety Functions] as displayed in the Safety Function Manager.



| Setting Ite | m                     | Function  | Remarks  |  |
|-------------|-----------------------|---|--|--|
|             | Model                 | Robot model name  | -  |  |
| Robot       | Parameter<br>Checksum | Parameter<br>checksum for<br>robot settings<br>(hidden)       | Robot model specific values.   |  |
|             | J1                    | Hofs value<br>for Joint #1                                    |  |  |
|             | J2                    | Hofs value<br>for Joint #2                                    |  |  |
|             | Ј3                    | Hofs value<br>for Joint #3                                    | Value for correcting the origin of the joint axis.  These values may vary by individual machine even within the same model.  |  |
| Hofs        | J4                    | Hofs value<br>for Joint #4                                    | (Unit: Pulse) The Hofs value for Joint #5 and Joint #6 are only displayed for a 6-Axis robot.  |  |
|             | J5                    | Hofs value<br>for Joint #5                                    |  |  |
|             | Ј6                    | Hofs value<br>for Joint #6                                    |  |  |
|             | Last<br>Modified      | Date and<br>time Hofs<br>was modified                         | -  |  |
| Safety      | Parameter<br>Checksum | Parameter<br>checksum for<br>safety<br>function<br>parameters | Specific value calculated from the safety function parameters for safety inputs, safety outputs, Safety Limited Speed (SLS), Safety Limited Position (SLP), Joint Angle Limit, Soft Axis Limiting, and Dry Run, as well as the safety function parameters last modified value. |  |
| Functions   | Last<br>Modified      | Date and<br>time safety<br>parameters<br>were<br>modified     | -  |  |


#### If an error is displayed when starting up Safety Function Manager

An error screen may be displayed when Safety Function Manager is started. Follow the instructions on each screen and take the following measures.

• If the robot model or robot parameter checksum is different Click the [OK] button.

Click [Send robot parameters to the Safety Board].


Follow the on-screen instructions, enter the safety board Password, and change the settings.



• If the Hofs value is different Click the [OK] button.

Click [Send Hofs to the Safety Board].

Follow the on-screen instructions, enter the safety board Password, and change the settings.




If the Dry Run settings are different
 Click the [OK] button to restart the Robot Controller.





#### 4.2.3 Changing Settings

1. Select the [Safety Function Settings] tab to display the [Safety Function Settings] screen.



2. Select the items for which you want to change the settings.





For details on settings, refer to the following section.

#### **Safety Function Parameters**



Parameters whose settings have been changed are displayed with a blue background. After applying the settings to the safety board, the display returns to normal.



## **★** KEY POINTS

If the set value of a safety function parameter is outside the input range, the background is displayed in yellow and the setting range is displayed in a pop-up. In this case, re-enter the value in the appropriate range.



## 4.2.4 Applying Settings

Finish editing the safety function parameters and display the confirmation screen.

1. Click the [Confirm] button.



2. Enter the safety board password on the password entry screen and then click the [Confirm] button.



#### KEY POINTS

- If an incorrect safety board password is entered three times, Safety Function Manager shuts down and the Robot Controller is restarted. Settings are not changed.
- 3. On the confirmation screen that appears, confirm the changed safety function parameters.


## KEY POINTS

- Settings cannot be changed on the confirmation screen. If you need to continue to make changes, click the [Cancel] button.
- If a setting item is displayed in yellow after clicking the [Confirm] button, an error in communication with the safety board has occurred. Restart both the Robot Controller and the PC on which Safety Function Manager is operating, and then perform the setting again. If the problem is still not improved, stop use of the robot system and contact the supplier.
- 4. Click the [Apply] button.

Safety Function Manager shuts down and the Robot Controller is restarted.



- 5. After the Robot Controller restarts, Epson RC+ will connect automatically.
- 6. Start Safety Function Manager and check to see if the parameters you changed have been applied.



 Safety function parameters should be applied to the safety board only after the safety manager has thoroughly checked the contents.

#### Cancelling

This cancels changes to safety function parameters.



Canceling before clicking the [Confirm] button will close Safety Function Manager without changing the safety function parameters of the safety board. The Robot Controller is not restarted at this time.

Canceling after clicking the [Confirm] button will close Safety Function Manager without changing the safety function parameters of the safety board. The Robot Controller is also restarted.

#### 4.2.5 Saving Settings (Performing a Backup)

The settings of Safety Function Manager can be saved using "Controller Backup" in Epson RC+. Backing up your settings allows you to restore the saved settings if you make a mistake when performing settings or if the safety board malfunctions. Be sure to perform a backup when changing the safety board settings, after teaching, and before performing maintenance.

#### **ℰ** KEY POINTS

Depending on the status of the device, backing up may not be available before maintenance. Be sure to always back up your latest settings.

#### Data that can be backed up

The backup saves the safety function parameters and the safety parameter last modified value.

- Safety inputs
- Safety outputs
- Safety Limited Speed (SLS)
- Safety Limited Position (SLP)
- Joint Angle Limit
- Soft Axis Limiting
- Dry Run

## KEY POINTS

For details on backup data other than the safety function parameters, refer to the following manual.

"Epson RC+ User's Guide"

#### **Backup procedure**

The backup is performed using "Controller Backup" in Epson RC+. For details, refer to the following manual. "Epson RC+ User's Guide"

For the restoration method, refer to the following section.

Restoring Saved (Backed-up) Settings


#### 4.2.6 Confirming Saved Information (Saved States Viewer)

You can refer to Safety Function Manager settings using the backup data saved with "Controller Backup" in Epson RC+. In Epson RC+ 7.0, open the [Controller] dialog box, and then select [View Controller Status]. For details, refer to the following manual.

"Epson RC+ User's Guide"

Refer to the SF GetParam function in the manual below for an explanation of the displayed setting values.

"Epson RC+ SPEL+ Language Reference"




## 4.3 Safety Function Parameters

This section describes the safety function parameters that set the Robot Controller safety functions.

# 4.3.1 Setting Safety Function Parameters Related to Safety Inputs and Safety Outputs

These settings are used by the safety input and safety output functions.



#### Safety input settings

These settings assign a function to be enabled for the safety inputs. For example, if you want to perform an emergency stop when a signal is input to SAFETY IN1, enable the checkbox at the intersection of SAFETY IN1 and ESTOP.

| No       | Name                     | Function                        | Notes   |  |  |  |
|----------|--------------------------|---------------------------------|---|--|--|--|
| 1. Safet | 1. Safety Input Settings |                                 |   |  |  |  |
| 1.1      | SAFETY_IN1               | Function setting for SAFETY_IN1 |   |  |  |  |
| 1.2      | SAFETY_IN2               | Function setting for SAFETY_IN2 |   |  |  |  |
| 1.3      | SAFETY_IN3               | Function setting for SAFETY_IN3 | Set the function for each safety input by assigning one of the "A. Safety Functions That Can Be Assigned" in the table below. |  |  |  |
| 1.4      | SAFETY_IN4               | Function setting for SAFETY_IN4 |   |  |  |  |
| 1.5      | SAFETY_IN5               | Function setting for SAFETY_IN5 |   |  |  |  |


| No                            | Name                                     | Function                         | Notes   |  |  |  |
|-------------------------------|--|----------------------------------|---|--|--|--|
| A. Safety F                   | A. Safety Functions That Can Be Assigned |                                  |   |  |  |  |
| Standard                      | ESTOP                                    | Emergency stop                   | ESTOP is assigned to SAFETY_IN1 by factory default.   |  |  |  |
| Functions                     | SG                                       | Protective stop                  | SG is assigned to SAFETY_IN2 by factory default.  |  |  |  |
| Safety<br>Function<br>Options | SLS_1,<br>SLS_2,<br>SLS_3                | Safety Limited<br>Speed (SLS)    | SLS_1, 2, and 3 can be assigned to safety inputs to set the safety outputs and the safety speed limit.  Refer to the following section for details.  Setting Safety Function Parameters Related to Safety Limited Speed (SLS)  SLS_T and SLS_T2 monitoring is enabled in the prescribed operation modes without having to be assigned to a safety input.  Refer to the following section for details.  Safety Limited Speed (SLS) |  |  |  |
|                               | SLP_A,<br>SLP_B,<br>SLP_C                | Safety Limited<br>Position (SLP) | SLP_A, B, and C can be assigned to safety inputs to set the safety outputs and monitored areas.  Refer to the following section for details.  Robot Installation Position Settings for Safety Limited Position (SLP)  |  |  |  |

## **⚠** CAUTION


- If ESTOP is not set for SAFETY\_IN, an emergency stop switch must be connected to the emergency stop input connector or a Teach Pendant must be connected.
- SG should be set to one or more SAFETY\_IN.

## **★** KEY POINTS

Settings for the safety inputs are divided into three groups.



- Any single group of safety functions can be selected for one SAFETY\_IN.
- Group 3 allows a combination of functions to be selected.
  - For SLS options, one can be selected.
  - For SLP options, an arbitrary combination can be selected. When SAFETY\_IN is turned ON, all combined functions will be enabled.



#### Safety outputs settings

These settings assign conditions for when the safety outputs output a signal. For example, if you want to output a signal from SAFETY\_OUT1 when STO is executed, enable the checkbox at the intersection of SAFETY\_OUT1 and STO.

| No       | Name           | Function                               | Notes   |
|----------|----------------|--|---|
| 2. Safet | y Output Ports |  |   |
| 2.1      | SAFETY_OUT1    | Function setting<br>for<br>SAFETY_OUT1 |   |
| 2.2      | SAFETY_OUT2    | Function setting for SAFETY_OUT2       | Set the function for each safety output port by assigning one of the "B. Safety Functions That Can Be Assigned" in the table below. |
| 2.3      | SAFETY_OUT3    | Function setting for SAFETY_OUT3       |   |

| No          | Name                                     | Function  | Notes  |  |  |  |  |
|-------------|--|---|--|--|--|--|--|
| B. Safety I | B. Safety Functions That Can Be Assigned |   |  |  |  |  |  |
|             | STO                                      | Outputs a signal when a Safe Torque OFF is executed.  | Refer to the following section for details.  Safe Torque OFF (STO) |  |  |  |  |
| Standard    | EP_RC                                    | Outputs whether the emergency stop button connected to the emergency stop input connector of the Robot Controller is On or Off. | Refer to the following section for details.  Emergency Stop        |  |  |  |  |
| functions   | EP_TP                                    | Outputs whether the emergency stop button on the Teach Pendant is On or Off.  | Refer to the following section for details.  Emergency Stop        |  |  |  |  |
|             | EN_SW                                    | Outputs whether the enable switch on the Teach Pendant is On or Off.  | Refer to the following section for details.  Enable                |  |  |  |  |

| No                              | Name                  | Function  | Notes  |  |
|---------------------------------|-----------------------|---|--|--|
| B. Safety                       | Functions That Can Be | Assigned  |  |  |
|                                 | SLS_T                 | Outputs whether Safety Limited Speed (SLS_T) is enabled or disabled.  | Refer to the following section   |  |
|                                 | SLS_T2                | Outputs whether Safety Limited Speed (SLS_T2) is enabled or disabled. | for details.  Safety Limited Speed (SLS)   |  |
| Optional<br>safety<br>functions | SLS_1,SLS_2,SLS_3     | Outputs whether Safety Limited Speed (SLS) is enabled or disabled.    | Safety Function options. A function can only be assigned to a safety output if it is assigned to a safety input. Refer to the following section for details. Safety Limited Speed (SLS)    |  |
|                                 | SLP_A,SLP_B,SLP_C     | Outputs whether Safety Limited Position (SLP) is enabled or disabled. | Safety Function options. A function can only be assigned to a safety output if it is assigned to a safety input. Refer to the following section for details. Safety Limited Position (SLP) |  |

## **▶** KEY POINTS

Multiple functions can be selected. When even one of the selected functions operates, a signal is output from the SAFETY\_OUT.

## 4.3.2 Setting Safety Function Parameters Related to Safety Limited Speed (SLS)

These settings are used by the Safety Limited Speed (SLS) function. Set the following items:

- TCP Offset
- Safety Limited Speed

#### **WARNING**

Be sure to set TCP Offset to properly operate Safety Limited Speed.


The TCP offset setting set in Safety Function Manager is not linked to the setting parameters set in the "Tool Settings" section of the "Epson RC+ User's Guide". Make sure that these settings are consistent.

#### KEY POINTS

- SLS\_1, SLS\_2, and SLS\_3 can be edited only when a function is assigned to the safety input.
- The TCP Offset should be set to the hand tip position\* using the Tool 0 coordinate system as a reference.
   \*: The position where the hand moves at its fastest during robot operation. Or, the position farthest from the tip of the ball screw linear motion mechanism.
- To achieve control that does not exceed the Safety Limited Speed (SLS), it must be explicitly set using the SPEL+ command.

The robot makes an emergency stop if Safety Limited Speed (SLS) is enabled and the robot speed exceeds the monitoring speed.

- If SLS\_1, SLS\_2, and SLS\_3 are enabled, the next SPEL+ command is automatically set when the controller starts up.
  - SLS number set in SF\_LimitSpeedS, 0
  - SLS number set in SF\_LimitSpeedSEnable, On
- SF\_LimitSpeedS and SF\_LimitSpeedSEnable are functions that adjust the speed at positions such as the tool
  position selected by the Tool command in conjunction with the Safety Limited Speed (SLS). For details, refer
  to the following manual.
  - "SPEL+ Language Reference"
- The speed of Monitored Joints can be acquired with SF\_PeakSpeedS/SF\_RealSpeedS. In addition, the joint speed of Monitored Joints can be acquired with PeakSpeed. For details, refer to the following manual.
   "SPEL+ Language Reference"



a: Control using SPEL+ to ensure that the Maximum Speed (mm/s) is not exceeded referring to the SF\_PeakSpeedS command value.

b: Referring to the PeakSpeed command values, control with SPEL+ to avoid exceeding the Maximum Joint Speed (%).

| No                     | Name  | Function   | Notes |
|------------------------|-------|--|-------|
| 1. TCP Offset Settings |       | These set the TCP Offset [mm].                     |       |
| 1.1                    | X_TCP | Setting for the offset position [mm] of the X axis | -     |
| 1.2 Y_TCP              |       | Setting for the offset position [mm] of the Y axis | -     |
| 1.3                    | Z_TCP | Setting for the offset position [mm] of the Z axis | -     |

| No                   | Name                   | Function   | Notes   |
|----------------------|------------------------|--|---|
| 2. Joint Angle Limit |                        | These configure settings related to the Joint Angle Limit. |   |
| 2.1                  | Check box              | Setting for whether to execute Joint Angle<br>Limit        | This is a function of SLS_1 (safety function option).   |
| 2.2                  | Maximum Joint<br>Angle | Setting for the limit angle [× 0.1 deg]                    | To use this, enable SLS_1 in the safety input settings. |

| No | Name               | Function   | Notes   |
|----|--------------------|--|---|
| 3  | SLS_T<br>Settings  | Setting for Maximum Speed in TEACH mode and TEST T1 mode | The following settings are available:  - Maximum Speed setting (required) Set at 250 [mm/sec] or less.  - Maximum Joint Speed setting (optional) This is always enabled for the Monitored Joints other than the Maximum Joint Speed. This cannot be disabled. |
| 4  | SLS_T2<br>Settings | Setting for Maximum Speed in TEST T2 mode                | The following settings are available:  - Maximum Speed setting (required)  - Maximum Joint Speed setting (optional)  This is always enabled for the Monitored Joints other than the Maximum Joint Speed. This cannot be disabled.                             |
| 5  | SLS_1<br>Settings  | Setting for Maximum Speed in SLS_1                       | Safety Function options. The following settings are available: - Maximum Speed setting (required) - Delay Time (optional) - Monitored Joints (At least one must be selected, including the Maximum Joint Speed) - Maximum Joint Speed setting (required)      |
| 6  | SLS_2<br>Settings  | Setting for Maximum Speed in SLS_2                       |   |
| 7  | SLS_3<br>Settings  | Setting for Maximum Speed in SLS_3                       |   |

| No  | Name                          | Function  | Notes  |
|-----|-------------------------------|---|--|
| A   | Maximum<br>Speed<br>(mm/s)    | Setting for Maximum Speed [mm/sec] in each limit                        | Make this setting based on the speeds that can be obtained with the SF_PeakSpeedS command and SF_RealSpeedS command.                           |
| В   | Delay<br>Time<br>(msec)       | Setting for Delay Time [ms] in each limit                               | -  |
| С   | Monitored<br>Joints           | Settings for Monitored Joints in each limit                             | Be sure to set up at least one joint.  |
| C.1 | J2                            | Setting for whether to monitor J2 speed                                 | -  |
| C.2 | Ј3                            | Setting for whether to monitor J3 speed                                 | This can only be set for a 6-Axis robot.   |
| C.3 | J5                            | Setting for whether to monitor J5 speed                                 | This can only be set for a 6-Axis robot.   |
| C.4 | Hand                          | Setting for whether to monitor hand speed (TCP speed)                   | -  |
| D   | Joint rotation setting        | Setting for joint speed monitoring in each limit                        | -  |
| D.1 | Joints                        | Setting for whether to monitor joint speed                              | -  |
| D.2 | Maximum<br>Joint<br>Speed [%] | Setting for Maximum Speed of joint axis rotation or vertical motion [%] | Set this as a percentage [%] of the maximum speed. Set this using the PeakSpeed command referring to the absolute obtainable peak speed value. |


#### 4.3.3 Robot Installation Position Settings for Safety Limited Position (SLP)

Set the robot installation position for using the Safety Limited Position (SLP) function. Set the following items:

- Installation Position
- Installation Plane Rotation

## **MARNING**

Be sure to set the Installation Position and the Installation Plane Rotation in order for the Safety Limited Position to operate properly.



| No                       | Name  | Function   | Notes                                    |
|--------------------------|-------|--|--|
| 1. Installation Position |       | Set the robot offset position [mm].                |  |
| 1.1                      | X_OFS | Setting for the offset position in the X direction | -  |
| 1.2                      | Y_OFS | Setting for the offset position in the Y direction | -  |
| 1.3                      | Z_OFS | Setting for the offset position in the Z direction | This can only be set for a 6-Axis robot. |

| No                             | Name  | Function                                       | Notes                                    |
|--------------------------------|-------|--|--|
| 2. Installation Plane Rotation |       | Set the robot offset angle [deg].              |  |
| 2.1                            | U_ROT | Setting for the offset angle around the U axis | -  |
| 2.2                            | V_ROT | Setting for the offset angle around the V axis | This can only be set for a 6-Axis robot. |
| 2.3                            | W_ROT | Setting for the offset angle around the W axis | This can only be set for a 6-Axis robot. |


#### 4.3.4 Setting Safety Limited Position (SLP)


Perform settings to use the Safety Limited Position (SLP) function. Set the following items:

- Robot Monitored Range
- Monitored Areas

## **ℰ** KEY POINTS

- SLP\_A, SLP\_B, and SLP\_C can only be edited if they are assigned to safety inputs.
- This does not perform control to prevent entry into the monitored areas. Perform the following settings as necessary.
  - . Set the XYZ limits (XYLim) so that the robot does not enter the monitored areas.
  - Set the entry detection area (Box) or the entry detection plane (Plane) considering the stopping distance
    around the monitored areas, and perform appropriate control when an entry is detected.
     For details on XYZ limits (XYLim), entry detection area (Box), and entry detection plane (Plane), refer to
    the following manual.
    - "Epson RC+ User's Guide", "SPEL+ Language Reference"
- For SCARA Manipulators, set the J3 axis monitoring radius to a value that encompasses the hand (end
  effector). This value is used to determine if the hand has entered the monitored areas.
- For 6-Axis Manipulators, set the J6 axis monitoring radius to a value that encompasses the hand (end effector). This value is used to determine if the hand has entered the monitored areas.





| No                       | Name  | Function  | Notes                                    |
|--------------------------|-------|---|--|
| 1. Robot Monitored Range |       | Set the safety monitoring radius [mm] for each joint. |  |
| 1.1                      | J2    | Setting for the monitoring radius for J2 axis         | -  |
| 1.2                      | Ј3    | Setting for the monitoring radius for J3 axis         | -  |
| 1.3                      | J5    | Setting for the monitoring radius for J5 axis         | This can only be set for a 6-Axis robot. |
| 1.4                      | Ј6    | Setting for the monitoring radius for J6 axis         | This can only be set for a 6-Axis robot. |
| 2                        | SLP_A | SLP_A-related settings                                | -  |
| 3                        | SLP_B | SLP_B-related settings                                | -  |
| 4                        | SLP_C | SLP_C-related settings                                | -  |

| No  | Name                  | Function   | Notes   |  |
|-----|-----------------------|--|---|--|
| A   | XY plane settings     | Setting for XY plane in each function                          | -   |  |
| A.1 | Enable setting        | Setting for whether to execute monitoring of the XY plane      | -   |  |
| A.2 | Range selection       | Selection of setting range - Wall - Restricted Area            | This can only be set if "A.1 Enable setting" is enabled.                              |  |
| В   | Enable XY plane range | Setting for whether to execute monitoring in each XY direction | This can only be set if "A.1 Enable setting" is enabled.                              |  |
| B.1 | X1 (Check box)        | Setting for whether to execute monitoring in the X1 direction  |   |  |
| B.2 | X2 (Check box)        | Setting for whether to execute monitoring in the X2 direction  | This can only be set when Wall is selected.  Be sure to enable at least one location. |  |
| B.3 | Y1 (Check box)        | Setting for whether to execute monitoring in the Y1 direction  |   |  |

| No  | Name                        | Function  | Notes   |  |
|-----|-----------------------------|---|---|--|
| B.4 | Y2 (Check box)              | Setting for whether to execute monitoring in the Y2 direction |   |  |
| С   | XY plane range input        | Setting for monitoring range in the XY direction              | This can only be set if "A.1 Enable setting" is enabled.              |  |
| C.1 | X1 (Text box)               | Setting for range in the X1 direction                         |   |  |
| C.2 | X2 (Text box)               | Setting for range in the X2 direction                         | Set X2 to a value greater than X1. Set Y2 to a value greater than Y1. |  |
| C.3 | Y1 (Text box)               | Setting for range in the Y1 direction                         |   |  |
| C.4 | Y2 (Text box)               | Setting for range in the Y2 direction                         |   |  |
| D   | Setting for the Z direction | Setting for monitoring in the Z direction                     |   |  |
| D.1 | Enable setting              | Setting for whether to execute monitoring in the Z direction  | Only Wall (floor, ceiling) can be set for the Z direction.            |  |
| Е   | Enable Z direction range    | Setting for whether to execute monitoring in the Z direction  |   |  |
| E.1 | Z1 (Check box)              | Setting for whether to execute monitoring in the Z1 direction | This can only be set if "D.1 Enable                                   |  |
| E.2 | Z2 (Check box)              | Setting for whether to execute monitoring in the Z2 direction | setting" is enabled.  |  |
| F   | Z direction range input     | Setting for monitoring range in the Z direction               |   |  |
| F.1 | Z1 (Text box)               | Setting for range in the Z1 direction                         | Set this to a value smaller than the robot                            |  |
| F.2 | Z2 (Text box)               | Setting for range in the Z2 direction                         | position. Set Z2 to a value greater than Z1.                          |  |

### Difference between a "Wall" and a "Restricted Area"

### Wall

The upper and lower limits of the robot's operating area are set, and if the robot moves from inside the set area to outside, then Safe Torque OFF (STO) is executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

#### **Precautions for Using the Robot Controller Safety Functions**

Please set the monitoring range considering the stopping distance. For the stopping distance, refer to the following manual. "Manipulator Manual - Appendix B. Stopping Time and Stopping Distance at Emergency Stop, Appendix C: Stopping Time and Stopping Distance When Safeguard Is Open"

Example of use: Preventing collisions with safety barriers

Refer to the following section for details.

**Monitoring Areas for a SCARA Manipulator** 

#### **Monitoring Areas for a 6-Axis Manipulator**

For a SCARA Manipulator, 15 patterns, (a) through (o) can specified for the restricted range on the XY plane, which correspond to Walls.

For a 6-Axis Manipulator, there are a total of 18 patterns, including three patterns, (q) through (s) for the monitored position in the Z direction, in addition to those specified for the restricted range on the XY plane, which correspond to Walls.

#### Restricted Area

A prohibited area is set within the robot's operating area, and if the robot moves from outside the set area to inside, then Safe Torque OFF (STO) is executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

#### **Precautions for Using the Robot Controller Safety Functions**

Please set the monitored areas considering the stopping distance. For the stopping distance, refer to the following manual. "Manipulator Manual - Appendix B. Stopping Time and Stopping Distance at Emergency Stop, Appendix C: Stopping

Time and Stopping Distance When Safeguard Is Open"

Example of use: Preventing collisions with structures near the robot

Refer to the following section for details.

Monitoring Areas for a SCARA Manipulator Monitoring Areas for a 6-Axis Manipulator

Pattern (p) corresponds to the Restricted Area.

## 4.3.5 Setting Soft Axis Limiting

Perform settings to use the Soft Axis Limiting function.

The setting range of Soft Axis Limiting is displayed to the right of the Soft Axis Limiting setting value. This setting range varies depending on the robot model.

# **MARNING**


The operating range set in Safety Function Manager is not linked to the setting parameters set in the "Tool Settings" section of the "Epson RC+ User's Guide". Set the operating range referring to the following.

# **ℰ** KEY POINTS

- The Soft Axis Limiting function is always enabled, except in TEACH mode.
- If any axis moves out of the motion range, Safe Torque OFF (STO) is executed and the robot is stopped. For details on the status, display, and notification of the Robot Controller when stopped by the safety function, refer to the following.

**Precautions for Using the Robot Controller Safety Functions** 

• The [Soft Axis Limiting] setting set in Safety Function Manager and the [Range] set in Epson RC+ can be set separately. We recommend setting [Range] to values equal to or narrower than those of [Soft Axis Limiting]. **EPSON** RC+ 7.0 Robot: 1, Robot1, GX8-B452S ▼ Local: 0 ▼ Tool: 0 ▼ Arm: 0 ▼ ECP: 0 ▼ 💼 🕥 👯 Range Arch Define limits for each robot joint Locals Tools Values are in encoder pulses Arms Pallets J1: -1128676 To 4405476 ECP To 2685156 J2: -2685156 J3: -1092267 0 То Defaults Planes -1668189 1668189 Weight XYZ Limits Range Read J1 Minimum Home Config Robot Manager Epson RC+ 8.0 Robot: 1, Robot1, GX8-B452S Motor: Off Range Points Define limits for each robot joint - Hands Arch J1: -1128676 To 4405476 J2: То -2685156 2685156 人 Locals J3: -1092267 To ₹ Tools To J4: -1668189 1668189 Arms Pallets Values are in encoder pulses ECP Read J1 Minimum ☐ Boxes Planes Weight XYZ Limits Range # Home Config



| No | Name                                    | Function   | Notes   |
|----|---|--|---|
| 1  | Setup<br>Method                         | Select [Pulse] or [Joint] as the setting method for the Soft Axis Limit.                               | -   |
| 2  | Pulse                                   | Set the minimum and maximum range for each axis as Pulse value.  | This can only be set when Pulse is selected in No.1. When Joint is selected, the Pulse value will automatically be modified based on the Joint value that is entered.                 |
| 3  | Joint                                   | Set the minimum and maximum range of each axis as angle (deg) or mm.                                   | This can only be set when Joint is selected in No.1. When Pulse is selected, the Joint value will automatically be modified based on the Pulse value that is entered.                 |
| 4  | Range                                   | Displays the minimum and maximum range for each axis.  | In the Safety function manager, the range setting cannot be changed. To change the setting, refer to the following.  "Epson RC+ User's Guide - [Tools]-[Robot Manager]- [Range] Page" |
| 5  | Set to<br>match the<br>range<br>setting | Automatically inputs the value of the Soft Axis Limiting of all axis based on the range setting.       | By pressing the button, it will automatically be input. Please note that previously input values will be overwritten  |
| 6  | Set to the limit value                  | Automatically inputs the value of the Soft Axis Limiting of all axis based on the Limit value setting. | By pressing the button, it will automatically be input. Please note that previously input values will be overwritten  |

# **CAUTION**

Setting the soft-axis limit to the limit value virtually eliminates the soft-axis limit. Be careful when using it. When entering the Pulse value, the Joint value is rounded down to the fourth decimal place, and the value is displayed with three decimal places.

When entering the Joint value, the Pulse value is displayed as an integer with the first decimal place rounded down.


The Safety board can be set with the Pulse value. Make sure to always check the input and displayed number.


# 4.3.6 SLP Viewer

This allows you create a 3D model to visualize the Monitored Areas and Robot Monitored Range edited in Safety Function Manager to check settings.

SLP Viewer is started by clicking the [Start SLP Viewer] button.

With SLP Viewer running, click the [Start SLP Viewer] button to update the display.





| No | Name   | Function  | Notes                                     |
|----|--|---|---|
| 1  | 3D model display section                         | Visualization of the Safety Restricted Area and Robot Monitored Range | There is no collision detection function. |
| 2  | Operation panel of the Robot<br>Monitored Range  | Select the monitoring area of the robot axis to be visualized         | -   |
| 3  | Operation panel of the Safety<br>Restricted Area | Select the safety area to be visualized                               | -   |

#### **Moving robot joints**

Drag the joints of the robot to move each joint of the robot. Selected joints are displayed in blue.

#### **Changing viewpoint**

Drag the 3D model display screen with the left mouse button to rotate the viewpoint.

Drag the 3D model display screen with the right mouse button to move the viewpoint up, down, left, or right.

### Zooming in or out


Move the scroll wheel to zoom in or out on the 3D display.

### KEY POINTS

- The Monitored Areas and Robot Monitored Range displayed in SLP Viewer are the values being edited in Safety Function Manager. The setting values may differ from those of the safety board.
- The robot posture displayed when SLP Viewer is started reflects the actual posture of the robot.
- The SLP Viewer is not linked to the actual robot motion.

# 4.3.7 Applying Safety Function Parameters

Apply the safety function parameters you changed to the safety board.



| No | Name       | Function  | Notes  |
|----|------------|---|--|
| 1  | Confirm    | Send the safety function parameters to the safety<br>board and display response values from the safety<br>board | Edit the necessary items before selecting this.  |
| 2  | Apply      | Apply the safety function parameters to the safety board  | Make sure there are no abnormalities in the response values before selecting this.                   |
| 3  | Cancelling | Cancel changes  | Clicking [Cancel] after clicking [Confirm] will cancel the changes and restart the Robot Controller. |

# 4.4 Making Dry Run Settings

When dry run is enabled, the Robot Controller can be executed without connecting it to a Manipulator.

Safety Function Manager provides dry run settings for both the Robot Controller and the safety board.


When switching between enabling and disabling dry run, the relationship between robot operation and the operation of safety functions by the safety board is as follows:

| Dry Run Settings | Robot Operation | Safety Functions |
|------------------|-----------------|------------------|
| Enabled          | Stopped         | Stopped          |
| Disabled         | Operating*      | Operating        |

<sup>\*:</sup> Be careful of the robot's operations.

### How to set dry run

On the [Safety Function Settings] tab, select [Enable Dry run].



# **ℰ** KEY POINTS

- Safety function parameters cannot be changed until dry run is disabled. However, the set values of the safety function parameters are retained.
- Dry run cannot be set with Epson RC+ for a Robot Controller equipped with safety functions.

# 4.5 Outputting the Safety Function Parameters to Text

To output the configured safety function parameters to the Robot Controller as text, implement the SPEL program as shown in the example below.

```
Function main
        Integer fileNum, i, j
        fileNum = FreeFile
        WOpen "c:\EpsonRC70\SFParam.csv" As #fileNum
        ' Outputs parameters acquired by the SF GetParam$ function as text
        Print #fileNum, "index, value"
        For i = 1 To 7
        Print #fileNum, Str$(i) + "," + SF GetParam$(i)
        Next i
        'Outputs parameters acquired by the SF_GetParam function as text
        Print #fileNum, "index, value"
        For j = 1 To 174
        Print #fileNum, Str$(j) + "," + Str$(SF_GetParam(j))
        Next j
        Close #fileNum
Fend
```

# **ℰ** KEY POINTS

For details on the SF\_GetParam\$ function, which returns safety function parameters, and the SF\_GetParam function (index corresponding to each safety function parameter), refer to the following manual.


"Epson RC+ Language Reference"

# 4.6 Safety Board Maintenance

# 4.6.1 Restoring Factory Default Settings

This function restores the safety function parameters set on the safety board to their factory default settings.

1. On the [Maintenance] screen, select [Defaults] to display the Safety Function Settings screen with default values added.



2. Use [Confirm] or [Apply] to set factory set Safety Function parameters for the Safety Board.



# **✗** KEY POINTS

This function does not change the safety board password. To change the safety board password, refer to the following section.


**Changing the Safety Board Password** 

## 4.6.2 Changing the Safety Board Password

This function changes the safety board password.

# **ℰ** KEY POINTS

- The safety board password must be changed by the safety manager.
- 1. On the [Maintenance] screen, select [Password].



2. Enter the current safety board password in [Current Password] and the new safety board password you want to set in [New password] and [Confirm Password], and then click [Update].

The Robot Controller is restarted.



# **ℰ** KEY POINTS

The safety board password must be eight characters or longer, but no more than 15 characters long. The characters that can be used are as follows:

Half-width uppercase alphabetic characters: A to Z

Half-width lowercase alphabetic characters: a to z

Half-width numbers: 0 to 9

Half-width symbols: (space)! "#\$ % & '() \* + , - . / : ; < = > ? @ [] ^\_{|}~

3. After the Robot Controller has restarted, start Safety Function Manager.

### KEY POINTS

- If an incorrect safety board password is entered three times, Safety Function Manager shuts down and the Robot Controller is restarted. At this time, the settings are not changed.
- The safety board password is always required when using Safety Function Manager. Please keep it in a safe place so that you do not forget it.
- If you need to reset the safety board password, contact your safety manager or the supplier.

### 4.6.3 Restoring Saved (Backed-up) Settings


#### **Restoration procedure**

A restoration can be performed using the [Restore Controller] in Epson RC+.

### **A** CAUTION

Be sure to perform the restoration on the same Robot Controller for which the data backup was performed. Also, do not rewrite the contents of the backup data. Operation of the robot system cannot be guaranteed if a restoration is performed using the data of a different Robot Controller or with rewritten data.

- 1. From the Epson RC+ menu, select [Tools] [Controller] to display the [Controller Tools] dialog box.
- 2. Click the [Restore Controller...] button to display the [Browse For Folder] dialog box.
- Specify the folder where the backup data is stored.
   B\_Robot controller name\_Serial number\_Date and time the backup was performed Example: B\_RC700-E\_12345\_2011-04-03\_092941
- 4. Click the [OK] button and select [Safety board configuration]. For other selection items, refer to the following manual.



5. Click the [OK] button.


6. Enter the safety board password on the password entry screen and then click the [Confirm] button.



# **№** KEY POINTS

Restore backup data saved in the backup of Robot Controller settings on the same system.

If you try to restore information from a different system, the following warning dialog box appears.



Except in special cases such as replacing a Robot Controller, click the [No] button.

- Restoring backup data from a system with safety function options enabled to a system with safety function options disabled does not set the option functions.
- If you check [Safety board configuration] or [Robot names, serial numbers, calibrations] in step 4, the safety board password authentication screen will be displayed.

### 4.6.4 Set the Robot Settings of the Controller to the Safety Board


The robot setting information that has been in the Controller can automatically be set to the safety board.

# KEY POINTS


- The setting function of the robot settings are available from Epson RC+ 8.0 or later.
- The robot's setting will automatically be set when you register and make changes. This will be used when error 9812 (Controller robot checksum value and Safety board settings differ.) has occurred after updating the Controller's firmware.

### **CAUTION**


- This will reset the safety function setting to factory settings. Set the safety function again afterwards.
   However, the safety board password will remain.
- Check the safety function's operation after setting the robots settings.
- 1. Click the [Set the robot settings] button on the [Maintenance] screen.



2. Check the warning message and click the [OK] button if you want to continue.




- 3. The contents of the settings to be written and the current Safety Board settings will be displayed. Confirm the contents of the settings to be written and click the [Confirm] button if there is no problem.
  - \*It is not a problem that the updated time of Hofs will be the current time which will be different from the Safety Board's settings.



4. Enter the Safety Board's passwords and click the [Confirm] button.



5. The contents of the settings to be written and the parameters sent to the Safety Board will be displayed. Make sure both settings are the same, and if there is no problem, click the [Confirm] button. By clicking the [Apply] button, the robot's set values and Hofs will be set on the safety board.



6. When the setting is complete, set the safety function according to the orders given on the screen.

# 4.7 How to Reset the Robot When It Stopped due to a Safety Function

If the robot was stopped due to a safety function, it must be reset to a status where it can operate again. Refer to the "How to reset" sections below and reset the robot.

- If the robot stopped due to a safety input: Example of Using Safety Input Functions
- If the robot stopped due to Safety Limited Speed (SLS): Example of Using Safety Limited Speed (SLS)
- If the robot stopped due to Joint Angle Limit: Example of Using Joint Angle Limit
- If the robot stopped due to Safety Limited Position (SLP): Example of Using Safety Limited Position (SLP)
- If the robot stopped due to Soft Axis Limiting: **Example of Using Soft Axis Limiting**

# 5. Example of Using Safety Functions

This section describes how to use each safety function, showing a simple example. For a detailed description of each function, refer to the Safety Function Manager screen.

# 5.1 Environment Required to Check Operation

The following describes the environment required to check operation.


### **Equipment configuration and applications**

Please prepare the following equipment and applications:

- Manipulator
- Robot Controller
- RC+
- Safety PLC
- Emergency stop switch
- Teach Pendant\*
  - \*Can be used when using the Safety Limited Position (SLP) and Soft Axis Limiting.

For details on available Controllers, Manipulators, and Applications, refer to the following. **System Configuration** 

#### **Equipment and wiring methods**



For the specific connection methods, refer to the following manual.

<sup>&</sup>quot;Robot Controller RC700-E Manual"

<sup>&</sup>quot;Robot Controller RC800-A Manual"

<sup>&</sup>quot;Robot Controller RC800L Manual"

# 5.2 Example of Using Safety Input Functions


The following describes an example of using safety inputs.

In this example, an Emergency Stop (ESTOP) function is assigned to SAFETY\_IN1, an emergency stop switch is connected to the SAFETY\_IN1 port, and the emergency stop switch is operated to confirm the safety input.


#### How to set

Follow the procedure below to set the safety function parameters.

1. In Epson RC+, select [Setup] - [System Configuration], and then start Safety Function Manager under [Controller] - [Safety Functions].



2. For [SAFETY\_IN1], select [ESTOP].




3. Apply settings.


#### How to check operation

Follow the procedure below to check the operation.

1. In Epson RC+, select [Tools] - [I/O Monitor], and then select [Safety Board].




2. Press the emergency stop switch connected to SAFETY IN1 to enable the emergency stop function.




As the safety inputs use negative logic, the Low level (0 V) is the ON status.

3. Confirm that SAFETY IN1 turns ON (white).



- 4. Confirm that the [EStop] displayed in the lower right corner of Epson RC+ lights up.
- 5. Release the emergency stop switch connected to SAFETY\_IN1 to disable the emergency stop function.





#### How to reset

Follow the procedure below to reset the emergency stop status.

- 1. Release the emergency stop switch.
- 2. Perform the reset operation.

EPSON RC+ 7.0: In EPSON RC+, select [Robot Manager] - [Control Panel], and then click the [Reset] button. Epson RC+ 8.0: In Epson RC+, select [Robot Manager] and then click the [Reset] button.

3. Confirm that the [EStop] displayed in the lower right corner of Epson RC+ turns off.

# 5.3 Example of Using Safety Output Functions


The following describes an example of using safety outputs.

In this example, the Safe Torque OFF (STO) function is assigned to SAFETY\_OUT1. By operating the emergency stop switch used to check the safety input, the safety output is confirmed by the status of the SAFETY\_OUT1 display on the Safety Board tab in the I/O monitor.


#### How to set

Follow the procedure below to set the safety function parameters.

1. In Epson RC+, select [Setup] - [System Configuration], and then start Safety Function Manager under [Controller] - [Safety Functions].



2. For [SAFETY OUT1], select [STO].




3. Apply settings.

#### How to check operation


Follow the procedure below to check the operation.

- 1. Press the emergency stop switch.
- 2. Confirm that the [EStop] displayed in the lower right corner of Epson RC+ lights up.
- 3. In Epson RC+, select [Tools] [I/O Monitor], and then select the [Safety Board] tab, and confirm that SAFETY\_OUT1 is ON (white).



4. Release the emergency stop switch.

5. Confirm that SAFETY\_OUT1 turns OFF (green).



#### How to reset

Follow the procedure below to reset the emergency stop status.

- 1. Release the emergency stop switch.
- 2. Perform the reset operation.

  EPSON RC+ 7.0: In EPSON RC+, select [Robot Manager] [Control Panel], and then click the [Reset] button.

  Epson RC+ 8.0: In Epson RC+, select [Robot Manager] and then click the [Reset] button.
- 3. Confirm that the [EStop] displayed in the lower right corner of Epson RC+ turns off.


# 5.4 Example of Using Safety Limited Speed (SLS)

The following describes an example of using the Maximum Speed of Safety Limited Speed (SLS). In this example, SLS 1 is assigned to SAFETY IN3 and the Maximum Speed of SLS 1 is set to 1000 [mm/sec].


#### How to set

Follow the procedure below to set the safety function parameters.

1. In Epson RC+, select [Setup] - [System Configuration], and then start Safety Function Manager under [Controller] - [Safety Functions].



2. For [SAFETY IN3], select [SLS 1].




3. For the TCP offset, enter [X\_TCP:0mm], [Y\_TCP:0mm], [Z\_TCP:0mm].

## *★* KEY POINTS

In this example, confirmation is performed without the hand attached. If 0 mm is entered for all the TCP Offset, a warning message will be displayed when you click the [Confirm] button. However, you can continue as-is.

4. For [SLS 1], select [Hand], and enter 1000 for [Maximum Speed] and 0 for [Delay Time].



5. Apply settings.

#### How to check operation

Follow the procedure below to check the operation.

- 1. Turn SAFETY IN3 ON (0V) to enable the speed monitoring function.
- 2. In Epson RC+, operate the robot at a speed of 500 mm/sec.

Sample program to operate at 500 mm/sec:

```
Function SLS_Test_500
    SF LimitSpeedS SLS 1, 500 'Sets the speed limit to 500 mm/s when SLS 1 is
enabled.
    SF LimitSpeedSEnable SLS 1, On 'Enables speed control when SLS 1 is enabled.
        Motor On
    Power Low
    Go P1
                       'Moves in PTP mode to the operation start position (P1).
    Power High
    Speed 100
    Accel 100, 100
    SF_PeakSpeedSClear 'Clears the peak speed value.
   Go P2
    SF PeakSpeedS
                       'Displays the peak speed value.
    Motor Off
Fend
```

### *▶* KEY POINTS

The safety functions do not operate because the operating speed is less than the Maximum Speed (1000 mm/sec).

3. In Epson RC+, change the speed to 1500 mm/sec and then operate the robot.

Sample program to operate at 1500 mm/sec:

```
Function SLS Test 1500
    SF LimitSpeedS SLS 1, 1500 'Sets the limit speed to 1500 mm/s when SLS 1 is
enabled.
   SF LimitSpeedSEnable SLS 1, On 'Enables speed control when SLS 1 is enabled.
   Motor On
   Power Low
    Go P1
                       'Moves in PTP mode to the operation start position (P1).
   Power High
    Speed 100
   Accel 100, 100
   SF PeakSpeedSClear 'Clears the peak speed value.
   Go P2
   SF PeakSpeedS
                       'Displays the peak speed value.
   Motor Off
Fend
```

4. Confirm that an emergency stop occurs and the robot operation stops.

#### How to reset

Follow the procedure below to reset the emergency stop status or error status. For details on safety functions, refer to the following section.

### **Precautions for Using the Robot Controller Safety Functions**

1. Perform the reset operation.

EPSON RC+ 7.0: In EPSON RC+, select [Robot Manager] - [Control Panel], and then click the [Reset] button. Epson RC+ 8.0: In Epson RC+, select [Robot Manager] and then click the [Reset] button.

2. Confirm that the [EStop] displayed in the lower right corner of Epson RC+ turns off.

# 5.5 Example of Using Joint Angle Limit

The following describes how to use Joint Angle Limit using SLS 1.

In this example, SLS\_1 is assigned to SAFETY\_IN3 to enable the Joint Angle Limit. Set the Maximum Joint Angle to 15 deg, and the SLS\_1 Maximum Speed to 1000[mm/sec]. Confirm that the Manipulator continues to operate as long as it does not violate the Maximum Joint Angle, and that any violation of Joint Angle Limit results in an emergency stop.




For details on the Joint Angle Limit, refer to the following section.

**Joint Angle Limit** 


#### How to set

Follow the procedure below to set the safety function parameters.


1. In Epson RC+, select [Setup] - [System Configuration], and then start Safety Function Manager under [Controller] - [Safety Functions].



2. For [SAFETY\_IN3], select [SLS\_1].



- 3. Select the [Joint Angle Limit]. When the [Joint Angle Limit] is selected, the [SLS\_1] delay time is fixed to 0.
- 4. Enter 150 for [Maximum Joint Angle].
- 5. Select [Hand] for [SLS\_1], and enter 1000 for [Maximum Speed].
- 6. Apply settings.




#### How to check operation

Follow the procedure below to check the operation.

1. Turn SAFETY\_IN3 ON (0V) to enable the Joint Angle Limit.

- 2. Turn on the robot motors.
  - EPSON RC+ 7.0: In EPSON RC+, select [Robot Manager] [Control Panel], and then click the [MOTOR ON] button. Epson RC+ 8.0: In Epson RC+, select [Robot Manager] and then click the [Motor: Off] button.
- 3. In Epson RC+, select [Tools] [Robot Manager] [Jog & Teach], and then set [Jog Distance] for J1 axis to 10 deg.
- 4. Click [+J1] to rotate 10 deg at low speed.




# **ℰ** KEY POINTS

As the jog distance (angle) is equal to or less than the limit angle (15 deg), the motor stays on without triggering the Safety Function.

5. Set [Jog Distance] for the J1 axis to 20 deg.

6. Click [+J1] to rotate 20 deg at low speed.



7. Confirm that an emergency stop occurs and the robot operation stops.

#### How to reset

Follow the procedure below to reset the emergency stop status or error status. For details on safety functions, refer to the following section.

#### **Precautions for Using the Robot Controller Safety Functions**

- Perform the reset operation.
   EPSON RC+ 7.0: In EPSON RC+, select [Robot Manager] [Control Panel], and then click the [Reset] button.
   Epson RC+ 8.0: In Epson RC+, select [Robot Manager] and then click the [Reset] button.
- 2. Confirm that the [EStop] displayed in the lower right corner of Epson RC+ turns off.


# 5.6 Example of Using Safety Limited Position (SLP)

The following describes an example of using Safety Limited Position (SLP). In this example, SLP\_A is assigned to SAFETY\_IN3 to confirm that an emergency stop occurs when the robot enters the restricted area. This example uses a GX8-B653S as the SCARA Manipulator and a C4-B901S as an the 6-Axis Manipulator.


# 5.6.1 Safety Limited Position (SLP) Settings for a SCARA Manipulator

Follow the procedure below to set the safety function parameters for the Safety Board.


1. In Epson RC+, select [Setup] - [System Configuration], and then start Safety Function Manager under [Controller] - [Safety Functions].



2. For [SAFETY\_IN3], select [SLP\_A].




3. In [Robot Monitored Range], enter 100 (mm) for [J2] and 80 (mm) for [J3].



4. Select the XY Plane in SLP A, and then select [Wall].

5. Enable the checkboxes for [X1], [X2], [Y1], and [Y2], then enter -700 (mm) for [X1], 700 (mm) for [X2], -700 (mm) for [Y1], and 700 (mm) for [Y2] as the positions of each Wall.



6. Check the set range in SLP Viewer.




7. Apply settings.


## 5.6.2 Safety Limited Position (SLP) Settings for a 6-Axis Manipulator

Follow the procedure below to set the safety function parameters for the Safety Board.


1. In Epson RC+, select [Setup] - [System Configuration], and then start Safety Function Manager under [Controller] - [Safety Functions].




2. For [SAFETY IN3], select [SLP A].




3. In [Robot Monitored Range], enter 99 (mm) for [J2], 99 (mm) for [J3], 48 (mm) for [J5], and 30 (mm) for [J6].



- 4. Select the XY Plane in SLP\_A, and then select [Wall]. Select the Z Direction as well.
- 5. Enable the checkboxes for [X1], [X2], [Y1], and [Y2], then enter -700 (mm) for [X1], 700 (mm) for [X2], -700 (mm) for [Y1], and 700 (mm) for [Y2] as the positions of each Wall. Enable the checkboxes for [Z1] and [Z2], then enter -700 (mm) for [Z1], and 700 (mm) for [Z2] as the positions of each Wall.



6. Check the set range in SLP Viewer.




7. Apply settings.

## 5.6.3 Confirming the Operation of the Safety Limited Position (SLP)

Follow the procedure below to check the operation.

1. Turn [SAFETY\_IN3] ON (0V) to enable the Safety Limited Position.

2. In Epson RC+, select [Tools] - [Robot Manager] - [Jog & Teach], and then move the robot to outside the wall (restricted area).



3. Confirm that an emergency stop occurs and the robot operation stops.

#### How to reset

The following three methods can be used to reset an emergency stop or error status. For details on safety functions, refer to the following section.


#### **Precautions for Using the Robot Controller Safety Functions**

- Method using safety inputs
- Method using the motor brake release
- Method using the Teach Pendant

## Method using safety inputs

1. Set [SAFETY\_IN3] to the OFF status (24 V) to disable Safety Limited Position.

- 2. Perform the reset operation.
  - EPSON RC+ 7.0: In EPSON RC+, select [Robot Manager] [Control Panel], and then click the [Reset] button. Epson RC+ 8.0: In Epson RC+, select [Robot Manager] and then click the [Reset] button.
- 3. Confirm that the [EStop] displayed in the lower right corner of Epson RC+ turns off.
- 4. Turn on the robot motors.
  - EPSON RC+ 7.0: In EPSON RC+, select [Robot Manager] [Control Panel], and then click the [MOTOR ON] button. Epson RC+ 8.0: In Epson RC+, select [Robot Manager] and then click the [Motor: Off] button.
- 5. In Epson RC+, select [Tools] [Robot Manager] [Jog & Teach], and then move the robot to inside the wall (outside the restricted area).




### Method using the motor brake release

How to Reset a SCARA Manipulator

1. Release the motor brake.

EPSON RC+ 7.0: In the EPSON RC+ [control panel]-[Free Joints], click the [Free All] button.



Epson RC+ 8.0: In the Epson RC+ [Jog & Teach]-[Free Joints], click the [Free All] button.

- 2. Move the robot by hand to outside the restricted area.
- 3. Perform the reset operation.

  EPSON RC+ 7.0: In EPSON RC+, select [Robot Manager] [Control Panel], and then click the [Reset] button.

  Epson RC+ 8.0: In Epson RC+, select [Robot Manager] and then click the [Reset] button.
- 4. Confirm that the [EStop] displayed in the lower right corner of Epson RC+ turns off.

How to Reset a 6-Axis Manipulator

Use the brake release unit (option) or the Brake command of the software. For details, refer to the following manual. "Manipulator Manual – Safety - How to Move Arms with the Electromagnetic Brake"

#### **Method using the Teach Pendant**

1. Attach the Teach Pendant to the Robot Controller and set the Robot Controller to TEACH mode.

# **A** CAUTION

When in TEACH mode, Safety Limited Position is disabled. Be careful of the robot's operations.

- 2. Operate the Teach Pendant to move the robot to outside the restricted area.
- 3. Change to AUTO mode and perform the reset operation using the Teach Pendant or Epson RC+.
- 4. Use the Teach Pendant or Epson RC+ to confirm that [EStop] is turned off.

## 5.7 Example of Using Soft Axis Limiting


The following describes an example of using the Soft Axis Limiting. This example uses a SCARA Manipulator as the robot. Note that the same procedure applies when using a 6-Axis Manipulator.

This example confirms that if the J1 axis moves outside the limit range, the robot enters the emergency stop status.

#### How to set

Follow the procedure below to set the safety function parameters.

1. In Epson RC+, select [Setup] - [System Configuration], and then start Safety Function Manager under [Controller] - [Safety Functions].




2. Enter a limit range value of each joint [J1] to [J4] set using Soft Axis Limiting as follows:

## Min [pulse]

J1:-1100000, J2:-2200000, J3:-1500000, J4:-1000000

#### Max [pulse]


J1:4400000, J2:2200000, J3:0, J4:1000000



### 3. Apply settings.

#### How to check operation

Follow the procedure below to check the operation.



1. In Epson RC+, select [Tools] - [Robot Manager] - [Jog & Teach], and then move the J1 axis to outside the limit range.

2. Confirm that an emergency stop occurs and the robot operation stops.

#### How to reset

The following two procedures can reset the emergency stop status or error status.

- Method using the motor brake release
- Method using the Teach Pendant


For details on safety functions, refer to the following section.

**Precautions for Using the Robot Controller Safety Functions** 

#### Method using the motor brake release

How to Reset a SCARA Manipulator

1. Release the motor brake. EPSON RC+ 7.0: In the EPSON RC+ [control panel]-[Free Joints], click the [Free All] button.



Epson RC+ 8.0: In the Epson RC+ [Jog & Teach]-[Free Joints], click the [Free All] button.

- 2. Move the robot by hand to inside the operating range.
- 3. In Epson RC+, perform the reset operation. EPSON RC+ 7.0: In EPSON RC+, select [Robot Manager] [Control Panel], and then click the [Reset] button.
  - Epson RC+ 8.0: In Epson RC+, select [Robot Manager] and then click the [Reset] button.
- 4. Confirm that the emergency stop state or error state is reset. For details on safety functions, refer to the following section.

  Precautions for Using the Robot Controller Safety Functions

How to Reset a 6-Axis Manipulator

Use the brake release unit (option) or the Brake command of the software. For details, refer to the following manual. "Manipulator Manual – Safety - How to Move Arms with the Electromagnetic Brake"

#### **Method using the Teach Pendant**

1. Attach the Teach Pendant to the Robot Controller and set the Robot Controller to TEACH mode.

# **A** CAUTION

When in TEACH mode, Soft Axis Limiting is disabled. Be careful of the robot's operations.

- 2. Operate the Teach Pendant to move the robot to inside the operating range.
- 3. Change to AUTO mode and perform the reset operation.